

Paragon3

(UHF / 800 MHz)

Data Base Station

User Manual V. 2.05

The entire contents of this manual are copyright 2006, 2007, 2008 by
DATARADIO Inc.

1. PRODUCT OVERVIEW	1
1.1 INTENDED AUDIENCE	1
1.2 GENERAL DESCRIPTION	1
1.1.1 Features	2
1.1.2 Configuration	2
1.3 FACTORY TECHNICAL SUPPORT	3
1.4 PRODUCT WARRANTY	4
1.5 REPLACEMENT PARTS	4
1.5.1 Factory Repair	4
1.6 PACKAGING	4
2. INSTALLATION	5
2.1 OVERVIEW	5
2.2 LOCATION	5
2.3 WARNING	5
2.4 REAR VIEWS	6
2.5 ELECTRICAL	7
2.5.1 Standard Power Supply Configuration	7
2.5.1.1 DC Power Supply Connection & Torque Settings	7
2.5.1.2 Power Indications	8
2.5.2 Backplane Fuses	8
2.6 ANTENNA	9
2.6.1 Overview	9
2.6.2 Cabling and Connection	9
2.7 COMPLETING THE PHYSICAL INSTALLATION	9
2.8 CHECKING OUT NORMAL OPERATION	9
3. OPERATING DESCRIPTION	10
3.1 RADIO ASSEMBLY	10
3.1.1 Receiver module	10
3.1.2 Exciter module	11
3.1.3 Power Amp module (T859 & T889)	11
3.1.4 BSC module	12
3.1.5 Speaker panel	12
3.1.6 Power Supply Modules (T809)	13
3.1.6.1 Power Supply Rear Connections	14
3.1.7 Radio Backplane Assembly	15
4. OPERATION & CONFIGURATION	16
4.1 BROWSER-BASED INTERFACE	16
4.1.1 Interface Setup and Status	16
4.2 LAN SETUP	17
4.3 DEFAULT IP SETTINGS	17
4.3.1 Ethernet Interface 1 (DATA)	17
4.3.2 Ethernet Interface 2 (SETUP)	17
4.3.3 RF Interface	17
4.4 IP NETWORK SETTINGS	18
4.4.1 IP Network Settings (with Host)	18
4.4.2 IP Network Settings (with Router)	18
4.5 LOGIN SCREEN	19
4.5.1 Initial Installation Login	19
4.6 WEB INTERFACE	20
4.6.1 Apply, Cancel, Save Config, and Reset Unit Buttons & Help Icon	20
4.7 BASIC AND ADVANCED PARAMETER SETTINGS	21
4.7.1 Unit Status	21
4.7.1.1 Unit Status ► General	21
4.7.1.2 Unit Status ► Radio Info	22
4.7.1.3 Unit Status ► Diagnostics	22

4.7.2	Setup (Basic)	25
4.7.2.1	Setup (Basic) ► General	25
4.7.2.2	Setup (Basic) ► Basic IP Configuration	26
4.7.2.3	Setup (Basic) ► Serial Ports Setup	27
4.7.3	Setup (Advanced)	28
4.7.3.1	Setup (Advanced) ► LAN (IP)	28
4.7.3.2	Setup (Advanced) ► RF (IP)	29
4.7.3.3	Setup (Advanced) ► Roaming	30
4.7.3.4	Setup (Advanced) ► IP Services Setup	31
4.7.3.5	Setup (Advanced) ► IP addressing modes	40
4.7.3.6	Setup (Advanced) ► IP Optimization & Tuning	50
4.7.3.7	Setup (Advanced) ► IP Routing	51
4.7.3.8	Setup (Advanced) ► Time Source	52
4.7.3.9	Setup (Advanced) ► Ethernet (PHY)	53
4.7.3.10	Setup (Advanced) ► Diagnostic Settings	54
4.7.3.11	Setup (Advanced) ► User Settings	58
4.7.4	Security	59
4.7.4.1	Security ► Password and Encryption Control	59
4.7.4.2	Security ► Access Control	60
4.7.5	Statistics	61
4.7.5.1	Statistics ► Interfaces	61
4.7.5.2	Statistics ► Performance	65
4.7.6	Maintenance	66
4.7.6.1	Maintenance ► Ping Test	66
4.7.6.2	Maintenance ► Config Control	67
4.7.6.3	Maintenance ► Package Control	68
4.7.6.4	Maintenance ► RF Tests	69
4.7.6.5	Maintenance Feature Options	70
4.7.6.6	Maintenance ► RSSI Display	70
4.7.6.7	Maintenance ► System Log	71
4.7.6.8	OOB Data ► Out of Band (GPS delivery)	74
4.7.7	Remote Table	75
4.7.8	Help	76
5.	TROUBLE-SHOOTING AND TESTING	77
5.1	EQUIPMENT REQUIRED	77
5.2	RECOMMENDED CHECKS	77
5.3	ADDITIONAL TEST DETAILS	81
5.3.1	Carrier Deviations	81
5.3.2	PF Switch	81
5.3.2.1	Stopping the Airlink and Alternate Test Tone Selection Method	81
5.4	WINDOWS/UNIX TOOLS	83
5.4.1	Network Connectivity	83
5.4.2	Configuration Information	83
5.4.3	Statistics Information	84
5.5	BSC FIRMWARE UPGRADING	84
5.5.1	Procedure	84
5.5.1.1	File Integrity Failure	85
6.	RADIO PROGRAMMING AND ADJUSTMENTS	86
6.1	SERIES II RADIO PROGRAMMING	86
6.1.1	Recommended Items	86
6.1.2	Module Programming	86
6.1.3	Channel Selection via DIP Switches	89
6.2	SERIES II RADIO TUNING	90
6.2.1	Test Equipment	90
6.2.2	Receiver module (T885-xx-0200, T855-xx-0250)	90
6.2.2.1	Initial Setup	91
6.2.2.2	Synthesizer Alignment	91
6.2.2.3	Front-End Alignment	92
6.2.2.4	SINAD and Linearity Check	92
6.2.2.5	RSSI Adjustment	93
6.2.3	Exciter Module (T881-xx-0200 or T857-xx-0250)	93

6.2.3.1	Initial Setup.....	93
6.2.3.2	Synthesizer Alignment.....	94
6.2.3.3	TX Frequency Error Adjustment.....	94
6.2.3.4	Low-Frequency Balance Adjustment.....	95
6.2.3.5	Exciter Power Output.....	95
6.2.4	Power Amplifier Module (T889 (800-870 MHz only) or T859 UHF).....	96
6.2.4.1	Power Amplifier Power Output.....	96
6.2.4.2	Forward Power Alarm Level (Optional setting).....	96
6.2.4.3	Reverse Power Alarm Level (Optional setting).....	96
6.2.4.4	Tait T859 (UHF) Standard Tuning Procedure.....	97
6.2.4.5	Tait T859 Tuning for Best Efficiency.....	97
7.	SPECIFICATIONS	104
FIGURE 1 -	FRONT VIEW "RADIO ASSEMBLY"	5
FIGURE 2 -	PARAGON3 UNIT REAR VIEW	6
FIGURE 3 -	BACKPLANE.....	6
FIGURE 4 -	MAXI-FUSE.....	8
FIGURE 5 -	RECEIVER MODULE	10
FIGURE 6 -	EXCITER MODULE	11
FIGURE 7 -	POWER AMP MODULE	11
FIGURE 8 -	BSC MODULE	12
FIGURE 9 -	SPEAKER MODULE	12
FIGURE 10 -	DUAL T809 POWER SUPPLY MODULE (BLACK FRONT PLATE)	13
FIGURE 11 -	T809 REAR PANEL (SHOWN UPRIGHT).....	14
FIGURE 12 -	RADIO BACKPLANE ASSEMBLY	15
FIGURE 13 -	WEB INTERFACE	16
FIGURE 14 -	IP NETWORK SETTINGS IN ROUTER MODE (WITH HOST)	18
FIGURE 15 -	IP NETWORK SETTINGS IN ROUTER MODE (WITH ROUTER).....	18
FIGURE 16 -	ENTER NETWORK PASSWORD SCREEN – ETH1 DATA PORT SHOWN	19
FIGURE 17 -	WEB USER INTERFACE – WELCOME SCREEN.....	19
FIGURE 18 -	UNIT IDENTIFICATION AND STATUS	21
FIGURE 19 -	UNIT STATUS - RADIO INFORMATION	22
FIGURE 20 -	UNIT STATUS – DIAGNOSTICS.....	22
FIGURE 21 -	BACKPLANE -TB1 CONNECTOR	24
FIGURE 22 -	TB1 CONNECTOR	24
FIGURE 23 -	SETUP (BASIC) – GENERAL SETUP	25
FIGURE 24 -	SETUP (BASIC) – BASIC IP CONFIGURATION.....	26
FIGURE 25 -	SETUP (BASIC) – SERIAL PORTS SETUP.....	27
FIGURE 26 -	ADVANCED IP CONFIGURATION - LAN (IP)	28
FIGURE 27 -	ADVANCED IP CONFIGURATION - RF (IP).....	29
FIGURE 28 -	ADVANCED IP CONFIGURATION – ROAMING.....	30
FIGURE 29 -	ADVANCED IP CONFIGURATION – IP SERVICES SETUP	31
FIGURE 30 -	NAT ENABLED ON PARAGON3	33
FIGURE 31 -	PARAGON3 - EXAMPLE 1	33
FIGURE 32 -	PARAGON3 - EXAMPLE 2	34
FIGURE 33 -	PARAGON3 - EXAMPLE 3	34
FIGURE 34 -	PARAGON3 - EXAMPLE 4	35
FIGURE 35 -	NAT ENABLED ON GEMINI3	35
FIGURE 36 -	GEMINI3 - EXAMPLE 1	36
FIGURE 37 -	GEMINI3 - EXAMPLE 2	36
FIGURE 38 -	SNMP: MANAGER/AGENT MODEL.....	37
FIGURE 39 -	BRANCH OF THE 1234.MIB OID TREE	38
FIGURE 40 -	BSC.MIB TREE	39
FIGURE 41 -	ADVANCED IP CONFIGURATION – IP ADDRESSING MODES	40
FIGURE 42 -	BROADCAST WINDOW DETAIL	42
FIGURE 43 -	EXAMPLE OF DIRECTED BROADCAST FORWARDING ENABLED	43
FIGURE 44 -	EXAMPLE OF DIRECTED BROADCAST FORWARDING DISABLED	44
FIGURE 45 -	EXAMPLE OF DIRECTED BROADCAST FORWARDING ENABLED	45
FIGURE 46 -	EXAMPLE OF LIMITED BROADCAST FORWARDING DISABLED	46
FIGURE 47 -	REGISTRATION TO MULTICAST GROUP (FIRST STEP).....	47

FIGURE 48 - RECEPTION OF MULTICAST PACKETS (SECOND STEP).....	47
FIGURE 49 - TYPICAL E-DBA MULTICAST GROUPS	48
FIGURE 50 - MULTICAST WINDOW DETAILS (ON THE BASE STATION)	49
FIGURE 51 - TYPICAL E-DBA MULTICAST GROUPS (WITH ADDRESSES)	49
FIGURE 52 - ADVANCED IP CONFIGURATION - IP OPTIMIZATION & TUNING - OIP (ROUTER MODE).....	50
FIGURE 53 - IP ROUTING	51
FIGURE 54 - ADVANCED IP CONFIGURATION – TIME SOURCE.....	52
FIGURE 55 - ADVANCED IP CONFIGURATION – ETHERNET (PHY)	53
FIGURE 56 - ADVANCED IP CONFIGURATION – DIAGNOSTIC SETTINGS	54
FIGURE 57 - SAMPLE INTERPOLATION CURVE.....	56
FIGURE 58 - SAMPLE CALIBRATION FILE.....	57
FIGURE 59 - ADVANCED IP CONFIGURATION - USER SETTINGS	58
FIGURE 60 - SECURITY – PASSWORD AND ENCRYPTION	59
FIGURE 61 - SECURITY - ACCESS LIST	60
FIGURE 62 - STATISTICS – INTERFACES	61
FIGURE 63 - LAYERS AND PROTOCOLS APPLICABLE TO DATARADIO IMPLEMENTATION	62
FIGURE 64 - LAYER, PROTOCOLS, AND INTERFACES APPLICABLE TO DATARADIO IMPLEMENTATION	63
FIGURE 65 - RX AND TX CONVENTION	63
FIGURE 66 - DATALINK ETHERNET STATISTICS.....	64
FIGURE 67 - DATALINK RF STATISTICS.....	64
FIGURE 68 - STATISTICS – CHANNEL UTILIZATION.....	65
FIGURE 69 - MAINTENANCE – PING TEST	66
FIGURE 70 - MAINTENANCE -CONFIGURATION CONTROL (INITIAL SCREEN)	67
FIGURE 71 - MAINTENANCE – PACKAGE CONTROL	68
FIGURE 72 - CONTROL - RF TESTS	69
FIGURE 73- MAINTENANCE – AVAILABLE FEATURE OPTIONS.....	70
FIGURE 74 - MAINTENANCE – RSSI DISPLAY.....	70
FIGURE 75 - MAINTENANCE –SYSTEM LOG.....	71
FIGURE 76 - A SYSTEM LOG ENTRY.....	71
FIGURE 77 - AN ASSERT TYPE SYSTEM LOG ENTRY	72
FIGURE 78 - OUT-OF-BAND	74
FIGURE 79 - REMOTE TABLE	75
FIGURE 80 - HELP ICON	76
FIGURE 81 - PF SWITCH ROCKER DETAIL (ONE SIDE PRESSED)	81
FIGURE 82 - SAMPLE FTP PROGRAM	85
FIGURE 83 - RECEIVER SYSTEM INFORMATION SAMPLE.....	87
FIGURE 84 - RECEIVER CHANNEL INFORMATION SAMPLE.....	87
FIGURE 85 - EXCITER SYSTEM INFORMATION SAMPLE.....	88
FIGURE 86 - EXCITER CHANNEL INFORMATION SAMPLE	88
FIGURE 87 - BACKPLANE DIP SWITCHES EXAMPLE - CHANNEL 5 SELECTED	89
FIGURE 88 - T855 AND T885, TYPICAL RSSI CURVE: VOLT TO DBM	93
FIGURE 89 - T859 TUNING SETTINGS.....	97
FIGURE 90 - T885-0200 RECEIVER TUNING CONTROLS LOCATION	98
FIGURE 91 - T881-0200 EXCITER TUNING CONTROLS LOCATION.....	99
FIGURE 92 - T855 RECEIVER TUNING CONTROLS LOCATION.....	100
FIGURE 93 - T857 EXCITER TUNING CONTROLS LOCATION.....	101
FIGURE 94 - T835 RECEIVER TUNING CONTROLS LOCATION	102
FIGURE 95 - T837 EXCITER TUNING CONTROLS LOCATION.....	103
TABLE 1 - ON-AIR DATA SPEEDS AND MODULATION.....	2
TABLE 2 - TEST POINTS	15
TABLE 3 - SAMPLE INTERPOLATION ENDPOINTS	56
TABLE 4 - PLICC SYNTAX	57
TABLE 5 - POSSIBLE ERROR MESSAGES	57
TABLE 6 - CHECKLIST A (AFTER INSTALLATION)	78
TABLE 7 - CHECKLIST B (GENERAL)	79
TABLE 8 - CARRIER DEVIATIONS.....	81
TABLE 9 – TEST TONES GENERATION.....	82

APPENDIX 1 - "GPS DATA COLLECTION" INSTRUCTIONS.....	106
APPENDIX 2 - E-DBA THROUGHPUT/LATENCY MEASUREMENTS METHODS	107
APPENDIX 3 - TIME SYNCHRONIZATION, AND WEB BROWSER CACHE - INSTRUCTIONS.....	109
APPENDIX 4 - ETHERNET CONFIGURATION - RECOMMENDATION	110

WHAT'S NEW

History

Versions 1.xx applicable to 700 MHz model (not covered in this manual)

Versions 2.xx applicable to UHF / 800 MHz models

Version 2.05 January 2008-Applies to E-DBA PROD V2.6_Rxxx

- Adds Section 4.7.6.7: Maintenance ► System Log
- Updates screen captures in Sections: 4.7.1.1, 4.7.3.4, 4.7.3.5.1, and 4.7.3.7.
- Updates Section 4.7.3.5: Setup (Advanced) ► IP addressing modes
- Updates Appendix 4.
- Updates Section 7: Specifications- *RF/Modem Assembly Size* and *Receiver Sensitivity*

Version 2.04 June 2007-Applies to E-DBA PROD V2.3_R219x

- Adds Section 4.7.1.3: Unit Status ►Diagnostics
- Adds Section 4.7.1.3.1: External Analog/Digital Inputs Monitoring
- Updates Section 4.7.3.4: Setup (Advanced) ► IP Services Setup
- Adds Section 4.7.3.4.2: SNMP Overview
- Updates Section 4.7.3.5: Setup (Advanced) ► IP addressing modes
- Adds Section 4.7.3.10: Setup (Advanced) ►Diagnostic Settings
- Adds Section 4.7.3.10.1: Calibration Files
- Adds Section 4.7.3.11: Setup (Advanced) ►User Settings
- Updates Section 4.7.4.2: Security ► Access Control
- Updates Section 4.7.5: Statistics

Version 2.03: March 2007 - Applies to E-DBA PROD V2.2_Rxxx

- Adds "Feature Key" optional functionality to section 1.2.1 "Features" and to Table 1 - On-air data speeds and modulation
- Restructures Section 4: Operation & Configuration
- Updates screen captures in Sections:4.7.1.1, 4.7.1.2, 4.7.3.2, and 4.7.7

Version 2.02: January 2007 -

- Rectifies typo on "About Dataradio" paragraph
- Rectifies caption and adds NPSPAC values to Table 1 - On-air data speeds and modulation
- Removes erroneous reference at Step 9 in Table 7 - Checklist B (General)
- Updates WEB pages: Section 4.7.2.3, 4.7.3.4, 4.7.3.5, 4.7.3.9, 4.7.4.2, 4.7.1.2, 4.7.6.2, 4.7.6.4
- Adds NPSPAC values to Table x - Carrier Deviations
- Updates Section 7, Specifications with NPSPAC values
- Adds Appendix 1 - "GPS Data Collection" Instructions
- Adds Appendix 2 - E-DBA Throughput/Latency Measurements Methods
- Adds Appendix 3 - Time Synchronization, and WEB Browser Cache - Instructions
- Adds Appendix 4 - Ethernet Configuration - Recommendation

- Updated section 6.2.1 to reflect current practices
- Updated Table 6, Table 7 and Table 8

Version 2.01: November 2006 -

- Updates Definition pages
- Updates Figure 12 - Radio Backplane Assembly
- Adds backplane Table 2 - Test Points
- Updates Table 7 - Checklist B (General)
- Adds Table 8 - Carrier Deviations
- Revises sensitivity specifications (section 7 Specifications)

Version 2.00: September 2006 -

- Initial release of common Paragon3 base station User Manual for 25 kHz channel 800 MHz & UHF radio modem models.



About Dataradio

For over 25 years, Dataradio has been a recognized and innovative supplier of advanced wireless data products and systems for mission-critical applications. Public safety organizations, utilities, local government, water management, and other critical infrastructure operations depend on Dataradio to ensure that vital wireless data reaches the people who need it, when they need it most. From mobile data systems and radio modems, to analog radios and telemetry devices, Dataradio products are found at the heart of private wireless networks around the world.

www.dataradio.com

Dataradio provides product brochures, case studies, software downloads, and product information on our website at <http://www.dataradio.com>

User Manual Statement

Every effort is taken to provide accurate, timely product information in this user manual.

Product updates may result in differences between the information provided herein and the product shipped. The information in this document is subject to change without notice.

About CalAmp Corp.

CalAmp is a leading provider of wireless communications products that enable anytime/anywhere access to critical information, data, and entertainment content. With comprehensive capabilities ranging from product design and development through volume production, CalAmp delivers cost-effective high quality solutions to a broad array of customers and end markets. CalAmp is a supplier of Direct Broadcast Satellite (DBS) outdoor customer premise equipment to the U.S. satellite television market. The Company also provides wireless data communication solutions for the telemetry and asset tracking markets, private wireless networks, public safety communications and critical infrastructure and process control applications.

www.CalAmp.com

For additional information, please visit <http://www.calamp.com>



DATARADIO and VIS are registered trademarks,
GeminiG3, Paragon3, PARALLEL DECODE, and TRUSTED WIRELESS DATA are trademarks of Dataradio Inc

A **CalAmp** Company

Definitions

Access Point	Communication hub for users to connect to a wired LAN. APs are important for providing heightened wireless security.
ADB	Agile Dual-Band - GeminiG3 radiomodem model that allows 700/800MHz automatic band switching capability during roaming.
AES	Advanced Encryption Standard (AES) - uses 128-bit encryption to secure data.
Airlink	Physical radio frequency connections used for communications between units.
ARP	Address Resolution Protocol – Maps Internet address to physical address.
AAVL	Autonomous Automatic Vehicle Location. Optional feature that involves using GPS (Global Positioning System) signals from the mobile unit by the Host PC.
Backbone	The part of a network that connects most of the systems and networks together, and handles the most data.
Bandwidth	The transmission capacity of a given device or network.
Base	Designates products used as base stations in VIS systems. They currently include the Paragon family of products up to the Paragon3.
Browser	An application program that provides a way to look at and interact with all the information on the World Wide Web.
BSC	Base Station Controller - An async controller-modem designed for the radio base station in mobile systems. A component of Paragon3 radiomodem base stations.
COM Port	RS-232 serial communications ports of the Paragon3 wireless radiomodem.
Cycle Mark	Signal transmitted on an E-DBA network that keeps the network synchronized.
Default Gateway	A device that forwards Internet traffic from your local area network.
DHCP	Dynamic Host Configuration Protocol - A networking protocol that allows administrators to assign temporary IP addresses to network computers by "leasing" an IP address to a user for a limited amount of time, instead of assigning permanent IP addresses.
DNS	Domain Name Server - The on-line distributed database system used to map human-readable machine names into IP addresses.
Domain	A specific name for a network of computers.
Dynamic IP Addr	A temporary IP address assigned by a DHCP server.
E-DBA	Enhanced Dynamic Bandwidth Allocation – Dataradio proprietary protocol that schedules all inbound and outbound Airlink traffic to minimize contention.
Ethernet	Ethernet is a frame-based computer networking technology for local area networks (LANs). It defines wiring and signaling for the physical layer, and frame formats and protocols for the media access control (MAC)/data link layer of the OSI model. Ethernet is mostly standardized as IEEE 802.3.
Feature Key	Method used to implement customer's option(s) selected at the time of radiomodem purchase (<i>factory-installation</i>) or as add-on (<i>field-installation</i>).
Firewall	A set of related programs located at a network gateway server that protects the resources of a network from users from other networks.
Firmware	The programming code that runs a networking device.
Fragmentation	Breaking a packet into smaller units when transmitting over a network medium that cannot support the original size of the packet.
FTP	File Transfer Protocol - A protocol used to transfer files over a TCP/IP network.

Gateway	A device that interconnects two or more networks with different, incompatible communications protocols and translates among them.
GeminiG3	Third generation of Gemini ^{PD} VIS products. High specs dual DSP mobile radiomodem with Dataradio Parallel Decode TM technology
HDX	Half Duplex. Data transmission that can occur in two directions over a single line, using separate Tx and Rx frequencies, but only one direction at a time.
HTTP	HyperText Transport Protocol - The communications protocol used to connect to servers on the World Wide Web.
IPCONFIG	A Windows 2000 and XP utility that displays the IP address for a particular networking device.
MAC ADDRESS	Media Access Control - The unique address that a manufacturer assigns to each networking device.
MIB	Management Information Base (MIB)-a logical, hierarchically organized database of network management information. Used in SNMP.
NAT	Network Address Translation - NAT technology translates IP addresses of a local area network to a different IP address for the Internet.
Network	A series of computers or devices connected for the purpose of data sharing, storage, and/or transmission between users.
Network speed	This is the <i>bit rate</i> on the RF link between units.
Node	A network junction or connection point, typically a computer or work station.
OID	An object identifier or OID is an identifier used to name an object and is the numerical equivalent of a path. In SNMP, an OID consists of numbers separated by decimal points. Structurally, an OID consists of a node in a hierarchically assigned namespace.
OIP	Optimized IP – Compresses TCP and UDP headers, and filters unnecessary acknowledgments. This makes the most use of the available bandwidth.
OTA	Over-The-Air - Standard for the transmission and reception of application-related information in a wireless communications system
Palette	Synchronization patterns used to identify the speed and coding of packets transmitted over-the-air in E-DBA.
Paragon3	IP-based data radio base station used in mobile networks and designed specifically to fit the needs of vehicular applications. Runs up to 128 kb/s
Parallel Decode	Technology featuring dual receivers for added data decode sensitivity in multipath and fading environments. (<i>United States Patent No: 6,853,694 B1</i>)
PHY	A PHY chip (called PHYceiver) provides interface to the Ethernet transmission medium. Its purpose is digital access of the modulated link (usually used together with an MII-chip). <i>The PHY defines data rates and transmission method parameters.</i>
PDU	Protocol Data Unit - A PDU is a message of a given protocol comprising payload and protocol-specific control information, typically contained in a header. PDUs pass over the protocol interfaces that exist between the layers of protocols.
Ping	Packet Internet Groper - An Internet utility used to determine whether a particular IP address is online.
PLC	Programmable Logic Controller. An user-provided intelligent device that can make decisions, gather and report information, and control other devices.
Roaming	Movement of a wireless node (GeminiG3) amongst Multiple Access Points (Paragon3). Paragon3 radiomodems support seamless roaming.
Router	A networking device that connects multiple networks together.

RS-232	Industry–standard interface for data transfer.
Smart Combining	Digital processing method used to combine “Spatial Diversity” signals to optimize performance. (See Parallel Decode)
SNMP	Simple Network Management Protocol - Provides a means to monitor and control network devices, and to manage configurations, statistics collection, performance, and security.
Spatial Diversity	Composite information from independent diversity branches using antennas spaced apart is used with “Smart Combining” to minimize fading and other undesirable effects of multipath propagation. (See Parallel Decode)
SRRCnFSK	Square Root Raised Cosine (n = level) Frequency Shift Keying. Type of frequency modulation of data signals performed by the Paragon3 radiomodem.
Static IP Address	A fixed address assigned to a computer or device that is connected to a network.
Static Routing	Forwarding data in a network via a fixed path.
Subnet Mask	A bit mask used to select the bits from an IP address that correspond to the subnet. Each mask is 32 bits long, with one bits in the portion that identifies a network and zero bits in the portion that identifies a host.
Switch (Ethernet)	Computer-networking device that allows sharing a limited number of ports to connect computing devices to host computers. Replaces network hubs (<i>layer1</i>), switches (<i>layer2</i>), routers (<i>layer3</i>).
Sync	Data transmitted on a wireless network that keeps the network synchronized.
TCP/IP	Transmission Control Protocol/Internet Protocol - A transport (<i>layer4</i>) protocol for transmitting data that requires acknowledgement from the recipient of data sent. Handles retries and flow control.
Telnet	Network (<i>layer5</i>) protocol used on the Internet or on LAN connections.
TFTP	Trivial File Transfer Protocol - A version of the TCP/IP FTP protocol that has no directory or password capability.
Topology	The physical layout of a network.
Transparent	A transparent unit transmits all data without regard to special characters, etc.
UDP	User Datagram Protocol - A transport (<i>layer4</i>) protocol for transmitting data that does not require acknowledgement from the recipient of the data that is sent.
Upgrade	To replace existing software or firmware with a newer version.
URL	Universal Resource Locator - The address of a file located on the Internet.
VIS	Vehicular Information Solutions. Dataradio’s name for a series of products specially designed for mobile data.
WINIPCFG	A Windows 98 and Me utility that displays the IP address for a particular networking device.
WLAN	Wireless Local Area Network - A group of computers and associated devices that communicate with each other wirelessly.

1. PRODUCT OVERVIEW

This document provides information required for the setting up, operation, testing and trouble-shooting of the Dataradio® Paragon3™ radio-modem base station.

1.1 Intended Audience

This document is intended for engineering, installation, and maintenance personnel.

1.2 General Description

The Paragon3 radio base station is a factory-integrated industrial-grade IP-based data product used in mobile networks and is designed specifically to fit the needs of vehicular applications. It features dual receivers for added data decode sensitivity in multi-path and fading environments.

When used with Dataradio's state-of-the-art GeminiG3 mobile IP data solution, the system delivers unequalled high-speed data performance and unmatched effective throughput.

All Paragon3 models are supplied in a standard 19-inch wide rackmount. The Paragon3 full-duplex radio-modem chassis assembly includes:

- A third generation high-speed Dataradio "Base Station Controller" module (BSC) that uses an open architecture that simplifies the implementation process. The BSC module comes equipped with a built-in IP router with dual Ethernet 10/100 BaseT interfaces.
- Two high-performance synthesized radio receiver modules.
- Single high-performance synthesized radio Exciter module.
- A user-adjustable Tait T859/T889 Power Amplifier (PA) module:
 - 20W to 100W in the UHF T859 models
 - 20W to 70W in the 800 MHz T889 models

For all Paragon3 radio modem units:

- Duplexer and backup power units are custom furnished items.
- Wire line modem(s) are optional items.
- Laptop PC and its application software are user-supplied items.
- Optional Router – Add a second router anywhere within your network if you need a fault tolerant network.

1.2.1 Features

- Parallel Decode™ technology featuring dual receivers for added decode sensitivity in multi-path and fading environments.
- Fully IP-based product models, using an optimized IP layer that reduces IP overhead for the RF link
- Sophisticated dual DSP-based modem design provides added system performance, fewer retries and more effective throughput.
- Full duplex mode of operation
- Base Station with an RF Power Amplifier (user adjustable from 20W)
 - 100W in the UHF T859 models
 - 70W in the 800MHz T889 models
- On-air data speeds and modulation types supported (*dependent on “Feature Key” selected¹*):

Table 1 - On-air data speeds and modulation

Modulation type	Channel Type			
	UHF		800 MHz	
	25 kHz	12.5 kHz	25 kHz	NPSPAC
SRC16FSK	64 kb/s	32 kb/s	64 kb/s	32kb/s
SRC8FSK	48 kb/s 43.2 kb/s	24 kb/s	48 kb/s 43.2 kb/s	24kb/s
SRC4FSK	32 kb/s	16 kb/s	32 kb/s	16kb/s

- Uses Dataradio’s Next generation high-efficiency Enhanced-DBA (E-DBA) over-the-air protocol
- Over-the-air compatible with GeminiG3 mobile products
- Out-of-band signaling enables transmission of GPS reports with no effect on system performance.
- Flash programmable firmware, including over-the-air programming capability

1.2.2 Configuration

Paragon3 units are factory-configured. Configuration changes or upgrades are web-based.

¹ Method used to implement customer’s option(s) selected at the time of radiomodem purchase (*factory-installation*) or as add-on (*field-installation*).

1.3 Factory Technical Support

The Technical Support departments of DATARADIO provide customer assistance on technical problems and serve as an interface with factory repair facilities. They can be reached in the following ways:

For Canada and International customers:

DATARADIO Inc.

5500 Royalmount Ave, suite 200
Town of Mount Royal
Quebec, Canada H4P 1H7

Technical support hours: Monday to Friday 9:00 AM to 5:00 PM, Eastern Time

phone: +1 514 737-0020
fax: +1 514 737-7883

Email address: support@dataradio.com
or

For U.S. customers:

DATARADIO Corp.

6160 Peachtree Dunwoody RD., suite C-200
Atlanta, Georgia 30328

Technical support hours: Monday to Friday 9:00 AM to 5:00 PM, Eastern Time

phone: 1 770 392-0002
fax: 1 770 392-9199

Email address: drctech@dataradio.com

1.4 Product Warranty

Warranty information may be obtained by contacting your sales representative.

1.5 Replacement Parts

This product is usually not field-serviceable, except by the replacement of individual radio modules. Specialized equipment and training is required to repair logic, modem boards, and radio modules.

Contact Technical Support for service information before returning equipment. A Technical Support representative may suggest a solution eliminating the need to return equipment.

1.5.1 Factory Repair

When returning equipment for repair, you must request an RMA (Returned Material Authorization) number. The Tech Support representative will ask you several questions to clearly identify the problem. Please give the representative the name of a contact person, who is familiar with the problem, should a question arise during servicing of the unit.

Customers are responsible for shipping charges for returned units. Units in warranty will be repaired free of charge unless there is evidence of abuse or damage beyond the terms of the warranty. Units out of warranty will be subject to service charges. Information about these charges is available from Technical Support.

1.6 Packaging

Each Paragon3 – UHF, 800 MHz, or 800MHz (NPSPAC) – radio-modem base station normally leaves the factory packaged as follows:

- A Dataradio base station “Radio-modem assembly” with dual power supply assembly, and a BSC.
- Two standard seven-foot 120 VAC power cords.
- Coax cable (16-inch) to connect the Exciter module to the power amplifier.

Frequently, Paragon3 product components are field-assembled prior to customer delivery.

The cabinetry may then be supplied in one of several custom rack-mount configurations that may also include fan, backhaul modems, duplexer/filters/combiners, and ancillary equipment.

If damage has occurred to the equipment during shipment, file a claim with the carrier immediately.

2. Installation




Figure 1 - Front view "Radio Assembly"

2.1 Overview

The cabinet and rack-mount housing the Paragon3's radio-modem and Power Amplifier is generally installed in a sheltered facility. Occasionally located adjacent to the nerve center of the user's network, it is often located near tower sites or at remote locations where it operates unattended.

Furnishings needed include power, cabling, and installation of antenna, landline or microwave modem, and host PC or portable computer. Details of these are outside the scope of this manual. This manual covers the radio-modem assembly and the power amplifier.

2.2 Location

Be sure to place the Paragon3 unit in such a way that:

- The LEDs can be seen (as an aid in troubleshooting)
- Access to the antenna connector and to the back connectors is possible without removing the unit
- Sufficient air may flow around the unit to provide adequate cooling.

2.3 Warning

Paragon3 radiomodem UHF and 800 MHz receiver modules (*RX1 and RX2 positions clearly identified in Figure 1 above and in Figure 2 on the next page*) are factory-adjusted as a pair and identified. Once tuned, they are not mutually interchangeable.

Always replace with a known adjusted and matched pair.

2.4 Rear Views




Figure 2 - Paragon3 unit rear view




Figure 3 - Backplane

2.5 Electrical

Standard 120 VAC electrical power is required. It should be capable of providing at least 10A to power Paragon3 unit (<6A) and ancillary equipment.

2.5.1 Standard Power Supply Configuration

Although the T809-10 is a high efficiency switched mode power supply, a considerable amount of heat is generated during normal operation. While in use, ensure that an adequate flow of cooling air is able to circulate around the power supply, and that the air intake vents on the rear and sides of the unit are not inadvertently covered.

Caution:

Do not operate this unit in a completely enclosed cabinet.

The Radio assembly unit receives 13.8 VDC power inputs from two “T809 ” power supply modules powered at 120 VAC. Normally used at room ambient temperatures, it can operate within its specifications over a range of –10 to +60 °C.

Note: Internal over-temperature protection shuts down the main transformer above 105° Celsius.

Both power supply modules are internally connected to ground via their individual, rear-connected, seven-foot standard 120 VAC power cords. The Radio Assembly chassis requires a secure ground connection. A threaded grounding binding post fitted with a knurled binding-nut is provided on the chassis next to DC input 2.

- For the Radio Assembly chassis, install the grounding lead's lug over the binding post and firmly hand-tighten the binding-nut.
- If a –DC rail (0V) is installed as part of the system, the grounding leads may alternatively be fitted to the rail terminal.

Caution:

Improper grounding between power supply case and rack frame may result in harmful voltage potentials and/or miscellaneous power supply switching noise problems in both receivers and transmitter.

2.5.1.1 DC Power Supply Connection & Torque Settings

Warning:

Securing the DC Power Supply cable into the DC connector to provide a good electrical connection is essential. Over time, the wires tend to compress in the DC connector resulting in an increasingly poorer connection. Consequently, as high current is drawn, the connector heats up increasing the resistance thereby causing still more heat until the connector eventually burns up.

Although screws securing DC cables to the Power Supply terminals are tightened to the torque settings given below prior to new system delivery, they must be re-tightened as part of the commissioning process and re-tightening is also part of the regular maintenance schedule.

Prior to replacing a Power Supply module into an existing system, inspect the cable and re-terminate the DC wires if the strands have previously been twisted together or show any sign of damage.

Cut the wire at the end of the insulation and then strip approximately .43 inch (11mm) of insulation off the cable. DO NOT TWIST THE WIRE STRANDS. Insert the DC cable into the screw terminal and tighten the screw to secure the cable as per the torque settings given below.

Torque Settings:

The manufacturer recommends torque setting all power supply terminal screws to a minimum of:

- 1.5 Nm (or 13.28 In/lb or to 1.107 ft/lb)

Note: Dataradio uses a Sturtuvan Richmond 29-pieces adjustable torque screwdriver model CAL36/4K.


After tightening, pull on the cable to check the cable is secured tightly into the screw terminal.

2.5.1.2 Power Indications

Both red-colored translucent power switches located on the front of the power supply modules illuminate when AC power is available. Toggle both to ON to distribute power to the Radio Assembly and to the Power Amplifier. The LED immediately below the switches light green indicating normal DC power operation.

2.5.2 Backplane Fuses

Blade fuses (Maxi-Fuse) are used on the Radio assembly backplane:



Fuse Type	Dimensions – Inch (mm)		
	A	B	C
Maxi-Fuse	1.15 (29.21)	1.35 (34.29)	.35 (8.89)

Fuse #	F1	F2	F3
Values	10A	15A*	15A*

* Always replace the two 15A fuses as a pair.

Figure 4 - Maxi-Fuse

2.6 Antenna

2.6.1 Overview

The Paragon3 unit commonly uses three antennas (one transmit and two receive) unless a duplexer is used with one of the receive antennas; then only two antennas would be needed. They should be mounted according to any guidelines supplied with the antennas. For antennas placement and spacing, consult System Engineering.

2.6.2 Cabling and Connection

- 1- Route good quality 50-ohm double-shielded coaxial cable(s) (e.g. RG-214 or Helix) from the selected antenna position(s) to the Paragon3 Radio assembly.
- 2- Referring to Figure 2 for locating modules, terminate the RX-1 and RX-2 cable-ends at their respective module rear position with N-type connectors.
- 3- Similarly, terminate the TX cable-end at the rear position of the Power Amp's module with an N-type connector.

Caution:

When terminating RF cables use brand-name crimping tools (such as AMP, Jensen, Crimp-Master, etc...) of the correct size for the cable and type of connector used.

Common pliers are NOT acceptable.

2.7 Completing the physical Installation

Paragon3 products are factory-configured to user's requirements and are shipped ready to run.

After new installations:

- Re-check that all connections are secure on the radio-modem assemblies (antennas, PC, power cords etc.)
- Check that fuses are inserted.
- Turn power supplies ON.

You are now ready to check for normal operation (as per paragraph 2.8) and to run the Dataradio web interface (described in section 4) for testing or trouble-shooting.

Any change(s) to the settings must be done via files saved on diskette and loaded into the unit using the web interface program.

2.8 Checking out Normal Operation

- 1- Check that power is applied.
- 2- Check Radio assembly lights for proper operation as per section 3.1
- 3- Check for proper operation of the BSCs LEDs.
- 4- Using the web interface program and an in-line wattmeter, check forward & reverse power to confirm main antenna installation.
- 5- Using the web interface, check the RF Data Link with a mobile that can be heard.

If user application and mobiles are available, test the installation by going through a normal sequence of transmitting and receiving messages.

3. Operating Description

3.1 Radio Assembly

The Radio assembly component of each Paragon3 – UHF & 800MHz product is made up of high performance synthesized radio base station designed for single operation. The Radio Assembly's modules are commonly installed in a standard, 19-inch wide rack frame.

The complement of modules is:

- 2 x Receiver modules
- 1 x Exciter module
- 1 x BSC (controller-modem)
- 1 x Speaker panel

and mounted on the rack (*normally immediately below the Paragon3 radiomodem*):

- 1 x Dual Power Supply module

3.1.1 Receiver module

Warning:

Paragon3 UHF and 800MHz receiver modules are factory-adjusted as a pair and clearly identified. Once tuned, they are not mutually interchangeable. Always replace with a known adjusted and matched pair.

For locating modules, refer to Figure 2 above.

The RX1 and RX2 receivers' have identical front panel controls and indicators. These are:

- Gating Sensitivity - sets the RF signal level required to open the mute gate and allow audio to pass to the speaker¹.
- Gate LED - indicates the status of the mute circuit. It is lit when a signal above the mute threshold is received¹.
- Supply LED - is lit when DC power is applied. Fast Flashes when linked with PGM800Win. Slow Flashes indicates PLL out of lock. Unequal Flashes indicates internal communication error.
- Line Level - Not used
- Monitor Volume - The audio output delivers up to 1 watt to the speaker. Always set volume knob to minimum when not in use to reduce current consumption.
- Monitor Mute Switch - opens the mute, allowing continuous monitoring of the audio signal. On = audio muted




Figure 5 - Receiver module

¹ "Gating Sensitivity" and "Gate LED" are not functionally used except to allow listening to incoming receptions as a trouble-shooting aid.

Depending on the sensitivity adjustment, the Gate LED lights and a relay can be heard on incoming RF signals.

3.1.2 Exciter module

The Exciter's front panel controls and indicators are:

- Carrier Switch - momentarily keys the transmitter ON while pressed (used for test purposes only).
- On LED - is lit when transmitting
- Line Sensitivity – not used.
- Supply LED - is lit when DC power is applied. Fast Flashes when linked with PGM800Win. Slow Flashes indicates PLL out of lock. Unequal Flashes indicates internal communication error.
- Microphone Socket – not used.




Figure 6 - Exciter module

3.1.3 Power Amp module (T859 & T889)

The power amplifier is maintenance free, only LED indications and a front panel adjustment are provided for the user.

As per Industry Canada Radio Standard Specification #131, paragraph 5.3:

"The manufacturer's rated output power of this equipment is for single carrier operation. It should not be used for multiple carrier operations."

The Power Amp front panel and indicators are:

- Supply LED - is lit when DC power is applied.
- Low Forward Power LED - is lit when forward power is below the level set, normally 80% of nominal forward power.
- High Reverse Power LED - is lit when high reverse power is detected (e.g. VSWR= 3:1).
- UHF Power - sets the PA output power 20 to 100 Watts.
- 800MHz Power - sets the PA output power 20 to 70 Watts.




Figure 7 - Power Amp module

3.1.4 BSC module

The BSC's front panel connectors and indicators are:

PWR LED	Green	Normal operation
	Amber	Step 2 in uMon boot-up – lights for <1 sec.
	Red	Step 1 in uMon boot-up – lights for <1 sec.
RX LED	Green	Flashes for each data packets received
	Red	Discard RX packet (factory-use)
TX LED	Green	Flashes for each data packets transmitted
	Amber	Flashes for each data packets transmitted (check for lost Host connection)
	Red	Continuously ON for TXON test (max. 20 secs.) Flashes ON for CWID key-up event
	Off	Check if in “AirLink down mode”
STATUS	Green	Flashes each time PF1 or PF2 is pressed
	Amber	Flashes each second PF1 is kept pressed Toggles “AirLink down mode” after 4 seconds

- 2x DE-9 RS-232 ports for setup and user data
- 1X rocker switch (positions PF 1 and 2) to select various test modes (see section 5.3.2 for details)
- 2x Ethernet ports – for setup and user data
- 2x Ethernet LEDs (status & activity)
- USB port – reserved.




Figure 8 - BSC module

3.1.5 Speaker panel

The speaker panel is fitted with a four-Ω speaker.

The RJ11 connector is used to allow programming the radio transmitter module (only) from the front of the unit via a programming lead.

If the speaker panel needs to be removed, a mirror programming port connector is provided on the backplane.




Figure 9 - Speaker module

3.1.6 Power Supply Modules (T809)




Figure 10 - Dual T809 Power Supply Module (black front plate)

Two horizontally mounted switched-mode pulse-width modulated T809 power supply modules are used but not connected in parallel.

Both power supply units have an ON-OFF switch* and one LED indicator on the front panel plus an output voltage adjust potentiometer (13.8 VDC nominal, 13.5 to 18 VDC) accessed via the back panel.

* To remove voltage from the power supply PCB, disconnect the main power cords.

Their circuit protection features are:

- Inrush current limiting
- Over-current (short-circuit)
 - 37 to 48A constant current limiting
 - Reset = auto recovery
- Over-voltage
 - 18 to 21 VDC = shutdown
 - Reset = Power OFF and ON
- Over-temperature
 - shutdown of output voltage
 - auto recovery with temperature reduction
 - temperature sensed on transistors and diodes

Front Panel Indications	
Power Switch	Illuminates when the unit is connected to AC power and voltage is available
ON LED	<ul style="list-style-type: none"> - Lights bright green when voltage output is normal - Lights faint green when module has entered over-current mode - Green LED is OFF, but power switch is ON indicates module has shut down due to over-temperature or over-voltage conditions.

3.1.6.1 Power Supply Rear Connections

The rear panel connections are:

- Auxiliary Inputs –

The DE-9 connector on the T809-10 rear panel provides access to the remote control of the power supply (*reserved for future use*).

- Output Voltage Adjust –

The output voltage of the power supply can be increased (up to 18V approximately) to compensate for the voltage drop lost along the cable. Access the trim-pot through a small hole on the rear panel.

To adjust the output voltage use a trimmer tool with a Phillips head or 3mm blade (*do not use a standard flat blade screwdriver to make the adjustment*):

- To increase the output voltage, turn the trim-pot clockwise.
- To decrease the output voltage, turn the trim-pot counterclockwise.

If the output voltage is increased on a power supply operating at, or close to, full load, the power supply loading must be reduced accordingly or the module may overheat and shut down.

- Feedthrough Terminal Block –

The DC Output Terminal block on the rear of the T809-10 is a Phoenix Contact HDFKV 10. This is a screw-type terminal connector that uses a cage mechanism to clamp the conductor(s). See section 2.5.1.1 for recommended torque settings.

- Protective Bonding Terminal –

The Radio Assembly requires a secure ground connection. See section 2.5.1 for connection details.

- 120 VAC Connector –

Use the supplied 10A-rated IEC type power cord.




Figure 11 - T809 Rear panel (shown upright)

3.1.7 Radio Backplane Assembly




Figure 12 - Radio Backplane Assembly

Table 2 - Test Points

Backplane Test Points			
Test		Pinout	Alternate Pinout
Ground		J1 – Pin 15	J9 – Pin 14
SINAD	RX1	J1 – Pin 6	J9 – Pin 3
SINAD	RX2	J5 – Pin 6	J9 – Pin 4
Distortion	RX1	J1 – Pin 6	J9 – Pin 3
Distortion	RX2	J5 – Pin 6	J9 – Pin 4
RSSI	RSSI 1	J1 – Pin 5	J9 – Pin 1
RSSI	RSSI 2	J5 – Pin 5	J9 – Pin 2

4. Operation & Configuration

Instructions and examples given in this manual are based on E-DBA operating software version current at the time of writing this document and may not apply to earlier or later software versions. Screen captures used throughout this document may vary from actual screens.

4.1 Browser-Based Interface

A built-in web server makes configuration and status monitoring possible from any browser-equipped computer, either locally or remotely. Status, configuration, and online help are available without requiring special client software. Setup is password-protected to avoid tampering or unauthorized changes.

Both the configuration parameters and operating firmware can be updated remotely, even over the RF network itself, using the standard File Transfer Protocol (FTP).




Figure 13 - Web Interface

4.1.1 Interface Setup and Status

The Paragon3 user interface is used to configure and view your network settings. Figure 13 shows the welcome screen of the Web Interface. The screen is subdivided in two frames: the frame on the left allows the user to navigate through the menus, while the main frame on the right displays the selected page. The menu system is two-leveled; some of the top-level menus expand to offer submenus. The *Site Map* link can be found right below the menus on the navigator pane. Help is available for each page displayed in the main frame. It can be accessed at all times by clicking the *Help* icon. The remaining buttons on the bottom of the Navigator frame are used to save your configurations and reset the unit.

4.2 LAN Setup

On a PC running MS-Windows with an existing LAN connection, connect either to the ETH1 (Data) or to ETH2 (Setup) RJ-45 input of the Paragon3 base station.

1. Click Start → Settings → Control Panel → Network and Dial-up Connection
2. Click on the relevant Local Area Connection
3. On the Local Area Connection Status screen, click Properties
4. On the Local Area Connection Properties screen, scroll the List Box until “Internet Protocol (TCP/IP)” is highlighted, click Properties
5. On the Internet Protocol (TCP/IP) Properties screen, follow either method below:
 - A) If using ETH2 (Setup LAN), select “Obtain an IP address automatically”
 - B) Select “Use the following IP address” → Enter 192.168.202.2 (*if ETH2 enter 192.168.203.2*) in the IP address field → 255.255.255.0 in the Subnet mask → Leave the Default gateway blank.
6. Click the OK button

*Note: On computers running Windows 9X, reboot to complete the connection process.
Steps above specifically apply to MS-Windows 2000. Modify as necessary for the OS you are running*

4.3 Default IP Settings

- Paragon3 radio modem supports the Router (IP Forwarding) mode

4.3.1 Ethernet Interface 1 (DATA)

- MAC: 00:0A:99:XX:YY:ZZ
- IP ADDR: 192.168.202.1
- NETMASKS: 255.255.255.0
- Default Gateway: 0.0.0.0
- DHCP Client Disabled
- RIPv2 Disabled

4.3.2 Ethernet Interface 2 (SETUP)

- MAC: 00:0A:99:XX:YY:ZZ + 1
- IP ADDR: 192.168.203.1
- NETMASKS: 255.255.255.0
- DHCP Server Disabled
- NAT Disabled

4.3.3 RF Interface

- MAC: 00:XX:YY:ZZ
- IP ADDR: 10.XX:YY:ZZ
- NETMASK: 255.0.0.0
- Compression Enabled
- Encryption Disabled

4.4 IP Network Settings

4.4.1 IP Network Settings (with Host)

Figure 14 below illustrates Paragon3 base station settings. In Setup (Advanced) → LAN (IP), set the data Interface 1 port (Eth1) IP addresses (set the setup Interface 2 port (Eth2)) and IP netmask of both Base and Mobile(s).

Keep the RF IP setting as is, providing customer is not using the 10.0.0.0 IP network.

Add routes in the Host (route add...)

In the illustration, Host and PC are part of different IP subnet




Figure 14 - IP Network Settings in Router Mode (with Host)

4.4.2 IP Network Settings (with Router)

Figure 15 below illustrates Paragon3 base station settings. In Setup (Advanced) → LAN (IP), set the data Interface 1 port (Eth1) IP addresses (set the setup Interface 2 port (Eth2)) and IP netmask of both Base and Mobile(s).

In the illustration, Host and PC are part of different IP subnet.




Figure 15 - IP Network Settings in Router Mode (with Router)

Keep the RF IP setting as is, providing customer is not using the 10.0.0.0 IP network.
Enable RIPv2 on Base station.

4.5 Login Screen

On the Address line of the Internet browser of your choice, type the factory-default IP addresses given to all Paragon3 radiomodem units: 192.168.20x.1 (*where x is 2 for the ETH1 Data port and 3 for the ETH2 Setup port*). Press Enter. The Enter Network Password screen opens.

A Windows-style dialog box titled "Enter Network Password". It contains a key icon and the text "Please type your user name and password." Below this, there are fields for "Site:" (containing "192.168.202.1"), "Realm:" (containing "SyncMaster"), "User Name:" (an empty text box), and "Password:" (an empty password box). At the bottom, there is a checkbox labeled "Save this password in your password list" which is unchecked. There are "OK" and "Cancel" buttons at the bottom right.

Figure 16 - Enter Network Password screen – ETH1 Data port shown

4.5.1 Initial Installation Login

For an initial installation, enter a User Name of 1 to 15 characters and the default Password ADMINISTRATOR (*upper case letters*). Click OK. The Web interface “Welcome” screen opens Figure 17.

For subsequent access to the Paragon3 unit, use the User Name and Password that you will have configured (*as detailed in section 4.7.4.1*).

Notes:

User Name field can be left blank. It only serves to identify the person gaining access.

Password is common and affects all User Name entries.


A screenshot of the Dataradio web user interface. The top has a red header with "DATARADIO" in white. Below it, a navigation menu on the left lists: Unit Status, Setup (Basic), Setup (Advanced), Security, Statistics, Maintenance, OOB Data, Remote Table, Site Map, Help, Save Config, and Reset Unit. The main content area has a "Welcome" heading and the text "Please use the links on the left to find your way around". It also includes a copyright notice "© 2007 Dataradio Inc." and a validation notice "This interface requires Internet Explorer 6+ or Firefox2+ Validated with: CSS HTML Validator 5". At the bottom left, there is a status bar showing "Ready".

Figure 17 - Web User Interface – Welcome Screen

4.6 Web Interface

The Paragon3 user interface (Figure 17) is used to configure and view your network settings.

To navigate, use the top-level menus on the left, some of which expand to offer submenus, and display the first submenu in the right-hand frame. Click the current submenu entry to refresh the right-hand frame. The tables starting at section 4.7.1 below list action of each function. The interface main screen lists available selections for the selected menu or presents instructions.

Notes:

At any time, click the Help icon in the navigation pane to open a help text relating to the window being displayed.

4.6.1 Apply, Cancel, Save Config, and Reset Unit Buttons & Help Icon

Several submenus have “Apply” and “Cancel” buttons.



The navigation area has “Save Config”, “Reset Unit” buttons and a Help icon.



If you “Apply” changes to any parameters marked  you will need to do a “Save Config” and a “Reset Unit”.

When making an entry into a dialog box, click on Apply when satisfied to temporarily apply the value(s) entered to the relevant parameter(s). If not satisfied, click on Cancel button to restore to the value(s) present before a change was made.

Note: Cancel command only affects the dialog boxes or option buttons in the opened window.

If needed, go to other submenu(s) and make more entries. Click Apply before leaving each window. When finished, click the Save Config button to make all changed entries permanent.

Notes:

“Apply” writes to RAM, thus failure to use the “Apply” command button before leaving a web page will result in the loss of temporarily entered selections, addresses, and values.

“Save Config” writes in flash, thus failure to use the “Save Config” command button will result in the loss of temporarily entered parameters. A “Reset” is required to make flash changes take effect.

Click on Save Config button:

- If there are changes to be saved, saving occurs automatically.
- If there are no changes to be saved, a sub-window prompts user to confirm saving.

Click on “Reset Unit” button:

- If there are changes to be saved, a window prompts user to confirm resetting.
- If there are no changes to be saved, resetting occurs automatically.

A “Station Reset” 20-second timer counts down while the status reports: “Working...”

When done, the status reports: “Ready”.

4.7 Basic and Advanced Parameter Settings

4.7.1 Unit Status

4.7.1.1 Unit Status ► General

Displays values that identify the unit and show its basic operating condition.

Dataradio Paragon3 E-DBA MULTIBAND PROD V2.6_R0711051600	
Station Name	Demo Unit
System ID	0
Local Time	2007-11-06 15:40:00
CWID Callsign	DATARADIO
CWID Interval	0
Unit Status	Ok
<input type="button" value="Acknowledge Unit Status"/>	

Figure 18 - Unit Identification and Status

Item	Description
Banner	Displays Paragon3 software revision information retrieved from the connected unit. Have this information handy if contacting Dataradio support.
Station Name	Displays name of connected unit. Configured under Setup Basic → General → Station Name
System ID	Displays System's unique identification number Configured under Setup Basic → General → System ID
Local Time	24-hour clock format display of the GMT time and date adjusted to the specified time zone. Configured under Setup Advanced → Time Source → Sntp
CWID Callsign	Continuous wave ID - Way of sending FCC license ID using Morse code. Continuous Wave Identification uses Morse Code to automatically send out the station ID periodically to identify the owner of the transmitting repeater. This satisfies the requirements of the FCC.
CWID Interval	Interval between CWID messages in minutes. Zero = never.
Unit Status	Normally displays "Ok" in the message area. Displays various warnings or messages in the event of hardware failure, If indications persist, have the status information handy if contacting Dataradio support.
Acknowledge Unit Status	Press this button to clear the Unit Status message area.

4.7.1.2 Unit Status ► Radio Info

Radio Information read-only table displays the serial number and model number of the installed radio modules. Paragon3 models that have both receivers combined into a single module will show the same information in the RX main and RX diversity rows.

	Serial #	Module
RX main	13141769	T885-10
RX diversity	13141777	T885-10
TX exciter	13012185	T881-10

Figure 19 - Unit Status - Radio Information

Item	Description
RX main	Indicates the Serial Number and Module model of the main receiver module
RX diversity	Indicates the Serial Number and Module model of the diversity receiver
TX exciter	Indicates the Serial Number and Module model of the transmitter/exciter module

4.7.1.3 Unit Status ► Diagnostics

Diagnostics values			
Analog values			
Item	Value	Status	Range
Chassis power supply	12.0 Volts	Normal	10.8 - 16.0 Volts
Power amplifier power supply	0.4 Volts	Fault	13.1 - 14.5 Volts
Forward power	0.0 Watts	Transmitter off	15.0 - 77.0 Watts
Reverse power	0.0 Watts	Alarm conditions not monitored	
Standing Wave Ratio	∞:1	Transmitter off	< 3.0
Chassis temperature	37 °C	Normal	15.0 - 40.0 °C
Analog monitoring 1	0.0	Normal	0.0 - 0.0
Analog monitoring 2	0.0	Normal	0.0 - 0.0
Digital values			
Item	Value	Status	
Alarm A1 input	Unasserted	Fault	
Alarm A2 input	Unasserted	Fault	
Alarm B1 input	Asserted	Fault	
Alarm B2 input	Asserted	Fault	
Refresh this frame to actualize values			

Figure 20 - Unit Status – Diagnostics

Item	Description								
Analog Values									
Chassis power supply	Displays chassis power supply voltage								
Power amplifier power supply	Displays power amplifier power supply voltage								
Forward power (J8-Tait_PA)	Displays forward power when the optional external power sensor assembly (p/n 030-03547-xxx) is installed. Note: Power measurement units (dBm or Watts) are user defined under Setup Advanced ► User Settings								
Reverse power (J8-Tait_PA)	Displays reverse power when the optional external power sensor assembly (p/n 030-03547-xxx) is installed. Note: Power measurement units (dBm or Watts) are user defined under Setup Advanced ► User Settings								
Standing Wave Ratio	Displays Standing Wave Ratio. Standing Wave Ratio (SWR) is computed as follows: $1 + \frac{\sqrt{\frac{ReversePower}{ForwardPower}}}{1 - \sqrt{\frac{ReversePower}{ForwardPower}}}$ Note: SWR is always computed-based on the forward and reverse power values in Watt, regardless of the power measurement unit chosen for display.								
Chassis temperature	Displays the internal unit chassis temperature. That temperature is usually 10 to 15°C higher than ambient room temperature. Default range: 15 to 40°C Note: Temperature measurement units are user defined under Setup Advanced ► User Settings								
Analog monitoring 1 (Ext_Fwd_Pwr_Sens)	Generic Analog input (0 – 8VDC) Displays user supplied analog input's measurement values								
Analog monitoring 2 (Ext_Rev_Pwr_Sens)	Generic Analog input (0 – 8VDC) Displays user supplied analog input's measurement values								
Digital Values									
Alarm A1 input (PS1_Fault)	Generic Alarm input. Signal goes low ("unasserted") to indicate a fault. Used with older Power Supplies versions (P/N: T807-10 & T808-10).								
Alarm A2 input (PS2_Fault)	Generic Alarm input. Signal goes low ("unasserted") to indicate a fault. Used with older Power Supplies versions (P/N: T807-10 & T808-10).								
Alarm B1 input (J8-Tait_PA)	Legacy support to Tait T859 & T889 PA Low Forward Power Alarm. Although not recommended, may be used with customized PA calibration (see section 6.2.4.2). Signal goes high ("asserted") to indicate low forward power Note: The "Low Forward Power" led on the front panel of the power amplifier turns red to indicate low forward power.								
Alarm B2 input (J8-Tait_PA)	Legacy support to Tait T859 & T889 PA High Reverse Power Alarm. Although not recommended, may be used with customized PA calibration (see section 6.2.4.3). Signal goes high ("asserted") to indicate high reverse power (> 3:1) Note: The "High Reverse Power" led on the front panel of the power amplifier turns red to indicate high reverse power.								
Status	For all digital and analog alarms displays alarm status: Normal or Fault. For Forward Power and Standing Wave Ratio (SWR) displays "Transmitter off" when the transmitter is off. Disregard the diagnostic value for SWR, Forward Power, and Reverse Power if the transmitter is off.								
Range	Displays range of values for all monitored analog diagnostic parameters. User-configurable under Setup (Advanced) ► Diagnostics. Recommended nominal ranges are: <table> <tr> <td>Chassis Power Supply</td><td>10.8-16.0 Volts</td></tr> <tr> <td>Power Amplifier Power Supply</td><td>10.8-16.0 Volts (with Tait PA)</td></tr> <tr> <td>Forward Power (700 and 800 MHz)</td><td>15. 0-77.0 Watts</td></tr> <tr> <td>Forward Power (UHF)</td><td>15. 0-110.0 Watts</td></tr> </table>	Chassis Power Supply	10.8-16.0 Volts	Power Amplifier Power Supply	10.8-16.0 Volts (with Tait PA)	Forward Power (700 and 800 MHz)	15. 0-77.0 Watts	Forward Power (UHF)	15. 0-110.0 Watts
Chassis Power Supply	10.8-16.0 Volts								
Power Amplifier Power Supply	10.8-16.0 Volts (with Tait PA)								
Forward Power (700 and 800 MHz)	15. 0-77.0 Watts								
Forward Power (UHF)	15. 0-110.0 Watts								

4.7.1.3.1 External Analog/Digital Inputs Monitoring

The user can connect and monitor two external analog and two external digital inputs to the backplane TB1 connector terminals (Figure 21 and Figure 22).




Figure 21 - Backplane -TB1 connector

TB1




Figure 22 - TB1 connector

An external analog device's voltage must not exceed 8 Volts. The default units of measure used for monitoring an external device are volts. It is possible to change the default units by creating a look-up table for the desired unit of measure. This look-up table is created following the guidelines in section 4.7.3.10.1 and is uploaded into the Paragon3 unit using FTP transfer. Refer to section 4.7.3.10 for more details.

Note 1: TB1 connector labeling differs on Figure 22 from the actual backplane:

TB1 / Web page name(s)	TB1 / Backplane name	Voltage input ranges
Analog monitoring 2 / Analog 2	Ext_Rev_Pwr_Sens	0 – 8 VDC
Analog monitoring 1 / Analog 1	Ext_Fwd_Pwr_Sens	0 – 8 VDC
Alarm A2 input	PS2_Fault	Active high*, > 4.75V to 30VDC
Alarm A1 input	PS1_Fault	Active high*, > 4.75V to 30 VDC

* An open condition or less than 2.0 VDC applied on those inputs is needed to guaranty the alarms won't trigger.

Note 2: The monitoring at the backplane J8-Tait_PA connector is usually not meaningful unless the optional external power sensor assembly (P.N.:030-03547-xxx) is purchased. That connector provides the base station Forward Power and Reverse Power monitoring signals as reported on the Paragon3 Diagnostics Web pages.

4.7.2 Setup (Basic)

4.7.2.1 Setup (Basic) ► General

Used to set four basic operating fields on the connected unit.

A screenshot of a 'General Setup' dialog box. It contains four input fields: 'Station Name' with the text 'Pollux', 'System ID' with the value '0', 'CWID Call sign' with the text 'DATARADIO', and 'CWID Interval' with the value '0' followed by the unit 'minutes'. At the bottom of the dialog are two buttons: 'Apply' and 'Cancel'.

Figure 23 - Setup (Basic) – General Setup

Item	Description
Station Name	Station name identifier – Enter string up to forty characters in length
System ID	Factory default ID is zero. To prevent collision and to minimize interference from remote systems that may be present on the same frequency, Dataradio recommends changing the System ID to some other value unique to each network. Upper limit is 255
CWID Call sign	Historically called “Continuous wave ID” – Way of sending FCC license ID using Morse code
CWID Interval	Interval between CWID messages in minutes Zero = never.

4.7.2.2 Setup (Basic) ► Basic IP Configuration

Sets the IP characteristics of the primary, or only, Ethernet port.


The image shows a 'Basic IP Configuration' dialog box. It has two main sections. The first section, 'Use fixed IP settings', is selected with a radio button. It contains three input fields: 'ETH 1 IP Address' with the value '192.168.36.27', 'ETH 1 Netmask' with '255.255.255.0', and 'Default Gateway' with '192.168.36.96'. The second section, 'Use DHCP Client', is unselected. It contains three empty input fields for 'ETH 1 IP Address', 'ETH 1 Netmask', and 'Default Gateway'. At the bottom are 'Apply' and 'Cancel' buttons. There are yellow warning icons next to the radio buttons and the input fields in the DHCP section.

Figure 24 - Setup (Basic) – Basic IP Configuration

Item	Description
Use fixed IP settings	Creates a fixed TCP/IP address connection. <i>You may need to ask your network administrator for the appropriate IP settings.</i>
ETH 1 IP Address	Set to valid unique IP address for each individual unit. Factory default is 192.168.202.1 for all Paragon3 units connected to their ETH1 port. For ETH2 configuration, see Setup Advanced ► LAN IP
ETH 1 Netmask	Set to valid IP netmask for each individual unit (<i>may be same or different depending on customer's IP network topology</i>).
Default Gateway	Set to valid Default Gateway. May change for different groups or locations
Use DHCP Client	Dynamic Host Configuration - Dynamically assigns an IP address
ETH 1 IP Address ETH 1 Netmask Default Gateway	These three read-only fields display the IP addresses obtained from the DHCP Server

4.7.2.3 Setup (Basic) ► Serial Ports Setup

The Paragon3 base station serial ports can be logically connected to local and remote services to aid in configuration and troubleshooting, or they can be connected to a remote Host application or even to the serial port of a remote unit.

Figure 25 - Setup (Basic) – Serial Ports Setup

Item	Description
Enabled	Independent check boxes to activate COM-1 PORT and/or COM-2 PORT
Speed	Select 300, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200 Baud Rate
Data Bits	Number of bits making up the data word. Set according to Host configuration. Default is 8.
Stop Bits	Mark the end of the serial port data type. Default is 1.
Parity	Added to identify the sum of bits as odd or even. Default is None.
Flow Control	Select None or CTS-based (RTU dependent)
Connection Control	Select Permanent (3-wire) or Switched (DTR bringup/teardown) (RTU dependent)
IP Gateway Service	Select one of: CLI Service (Command line interface) RS-232 connection to Host PC (Default = SETUP) Custom – Choosing Custom enables the IP Gateway Transport configuration
IP Gateway Transport	Available only if IP Gateway Service selection is Custom, choose the socket connection mode from the drop-down list box choices of TCP Server, TCP Client, or UDP.
Local IP Address	Valid unicast or multicast IP address, including the local Loopback interface address. Default local IP address is set to 0.0.0.0 and can be changed dynamically without a unit reset.
Local IP Port	For TCP Client and UDP socket connections, set to any value between 1 and 65535. For TCP Server socket connections, set to any value between 1 and 65535 but must not be set to one of the following values or fall within the following ranges of values: 20, 21, 23, 123, 520, 5002, 6254 to 6299, 7000 to 7100. Otherwise, the parameter configuration will be accepted, but no socket connection will be established to accept connection from remote endpoints. Default local port value is set to 1024 and can be changed dynamically without a unit reset.
Remote IP Address	Default remote IP address is the Loopback interface address, 127.0.0.1 and can be changed dynamically without a unit reset
Remote IP Port	For socket connection modes (TCP active, UDP), set to any value between 1 and 65535. Default local port value is 23 and can be changed dynamically.
Status	Can be UP, READY, or DOWN. Click on the “Refresh” word in the “(Refresh this frame to confirm “Status”)” sentence to update Status condition.

4.7.3 Setup (Advanced)

4.7.3.1 Setup (Advanced) ► LAN (IP)

Allows the setting of IP characteristics beyond those set in “Setup (Basic)” ➔ “Basic IP”.

When a mobile registers with a new base, the base may send a message to each of its neighbor to assure that their Internet tables are up-to-date. Up to 32 neighbors can be entered. *An empty or incomplete table may cause IP routing problems when the mobile roams.*

Figure 26 - Advanced IP Configuration - LAN (IP)

Item		Description
Interface 1 (ETH1)	IP Address Netmask	Read-only fields showing “IP Address” and “Netmask address” defined earlier in “Setup (Basic)” ➔ “Basic IP”.
	MTU	Ethernet Interface MTU - Default 1500. – For optimal performance, set at 1500. Entering a value lower than 1500 may reduce system performance. Flexibility of using lower values may be useful in testing or for particular operational conditions. Range is 576 to 1500.
	MAC address	Ethernet Interface MAC address in HEX format (<i>factory-set</i>).
Interface 2 (ETH2)	IP Address	Set to valid unique IP address for each individual unit. Factory default is 192.168.203.1 for all Paragon3 units connected to their ETH2 port. For ETH1 configuration, see Setup Basic ➔ Basic IP Configuration
	Netmask	Set to valid IP netmask for each individual unit (<i>may be same or different depending on customer's IP network topology</i>).
	MTU	Ethernet Interface MTU - Default 1500. – For optimal performance, set at 1500. Entering a value lower than 1500 may reduce system performance. Flexibility of using lower values may be useful in testing or for particular operational conditions. Range is 576 to 1500.
	MAC address	Ethernet Interface MAC address in HEX format (<i>factory-set</i>).
Neighbouring Bases	Add	Type in the “Neighboring Bases” field the IP address in dot decimal format of the base to be added to the neighboring “Base List” table.
	Delete	Type in the “Neighboring Bases” field the IP address in dot decimal format of the base to be deleted from the neighboring “Base List” table.
	Base List	Read-only listing. Dynamic window expands downward as needed to show all addresses added to the list or shrinks as addresses are removed. Shows “Table is empty” if no address is present in the Base List.

4.7.3.2 Setup (Advanced) ► RF (IP)

At the time of manufacture, each Paragon3 base station and Gemini G3 radio modem is provided with a unique MAC address for its Ethernet and RF interfaces. These addresses cannot be changed. The RF interface is also provided with a unique Factory RF IP address. If this IP address conflicts with any existing IP network, it can be overridden.

Figure 27 - Advanced IP Configuration - RF (IP)

Item	Description
RF MAC	RF Interface MAC address in HEX format (<i>factory-set</i>).
RF IP Address	Displays factory-assigned address: nnn.nnn.nnn.nnn “Factory”
	Entering 0.0.0.0 sets the RF IP Address to the factory default and highlights the “Factory” name (active address) Entering nnn.nnn.nnn.nnn (RF IP Address of your choice) overrides the factory default and highlights the “Override” name (active address)
RF Net Mask	Set to valid common IP netmask for all units within a Paragon3 network
RF MTU	RF Interface MTU - Default 1242. – For optimal performance, set at 1242. Entering a value other than 1242 may reduce system performance, especially if set to a higher value. <i>Flexibility of using other values may be useful in testing or for particular operational conditions.</i> Range is 576 to 1500.
Airlink Speed	Lists the choice of Airlink speeds, the nominal speed at which data packets are transmitted over-the-air in E-DBA. <i>The mobile will automatically adapt to the base station.</i> e.g.: At 800MHz Full Channel, the choices are: 64kb/s 48kb/s 43.2kb/s 32kb/s

4.7.3.3 Setup (Advanced) ► Roaming

The “Host Link Active” feature allows a base to assure the communication backhaul is operating. If not, the base indicates to mobiles on the channel that they should promptly roam to another base

The “Base Loaded” feature monitors the amount of network traffic during the previous 10-second period. If there are more than a certain number of mobiles actively sending data and the channel is occupied above a certain percentage, then the base indicates that a portion of the registered mobiles should roam to other bases, until channel loading falls below the thresholds.

Figure 28 - Advanced IP Configuration – Roaming

Host Link Active (on ETH1)	
Link check is...	Disabled (Default), Enabled
Host address	IP address of a router/host to be pinged periodically
Ping failure threshold	This many failed pings in a row are needed to mark the “Host is...” field as “Unreachable”
Ping success threshold	This many successful pings in a row are needed to mark the “Host is...” field as “Reachable”
Ping every	How often to send a ping
Host is ...	Current status of the host link (blank if disabled)
Base Loaded	
Feature is...	Disabled, Enabled
Mobile Limit	Minimum number of active mobile before channel can be considered “Loaded”
Percentage Threshold	Minimum percentage of data capacity before channel can be considered “Loaded”
Base is...	Current status of the base (blank if disabled)

4.7.3.4 Setup (Advanced) ► IP Services Setup

IP Services Setup

DHCP Server (ETH2 only)

Server !	<input checked="" type="radio"/> Disabled <input type="radio"/> Enabled	
Gateway !	192.168.203.1 <input type="text" value="0.0.0.0"/>	<input checked="" type="radio"/> Preset <input type="radio"/> Override
Lease start address !	<input type="text" value="192.168.201.2"/>	
Lease duration !	<input type="text" value="720"/> mins	
Maximum number of leases !	<input type="text" value="10"/>	

IPSD !
 ☐ Disabled
☒ Enabled

NAT (ETH2 only) !
 ☒ Disabled
☐ Enabled

RIPV2 (ETH1 only) !
 ☐ Disabled
☒ Enabled

SNMP !
 ☐ Disabled
☒ Enabled

☐ Add !
☐ Delete

Trap IP List 192.168.36.202
MIB [Download mibs.zip](#)

Figure 29 - Advanced IP Configuration – IP Services Setup

Item	Description
Server	DHCP Server Disabled, Enabled (Default). The Dynamic Host Configuration Protocol provides a framework for passing configuration information e.g.: IP address to Hosts (i.e. PC/RTU) on a TCP/IP network.
Gateway	Gateway address handed out by the DHCP Server to the DHCP Client. The default value is set to the IP address of the Ethernet 2 interface. If the gateway is set to 0.0.0.0, no gateway address will be handed out by the DHCP Server.
Lease Start Address	Pool of addresses allocated for DHCP purpose. If a unit is configured as DHCP Server, this field represents the start IP address pool managed by the DHCP Server. Normally, Paragon3 automatically calculates the Lease Start Address (equal to Ethernet IP Address plus one).
Lease Duration	The period over which the IP Address allocated to a DHCP client is referred to as a “lease”. Lease Duration is the amount entered in minutes. A value of “0” indicates an infinite lease.
Maximum number of leases	Maximum number of DHCP client(s) a unit can serve.
IPSD	IP Services Delivery – Disabled (Default), Enabled. Allows or disallows the generation of locally provided IP Services such as online diagnostics, alarms, etc...
NAT (ETH2 only)	Network Address Translation - Disabled, Enabled (Default) NAT technology is a method by which IP addresses are mapped from one address space to another. In Paragon3, it is normally used on the WAN side of an IP network to hide local IP addresses from an external IP network (i.e. Internet). See section 4.7.3.4.1 for a more detailed description.
RIPV2 (ETH1 only)	Router Information Protocol v2 - Disabled, Enabled (Default) RIPv2 is a dynamic IP routing protocol based on the distance vector algorithm and is only used in Router mode.

Item	Description
SNMP	<p>Simple Network Management Protocol – Disabled, Enabled (Default)</p> <p>SNMP provides means to monitor, collect, and analyze diagnostic information. Enabling SNMP allows the MIB (Management Information Base) in the Paragon3 to be viewed using an external MIB browser or network management software.</p> <p>Trap IP List</p> <p>After reset, the Paragon3 sends a WARMSTART trap to all of the IP addresses defined in the Trap IP list. It signifies that the system has started.</p> <p>To add an address to the Trap IP List: Select <i>Add</i> and type the new IP address to be added to the read-only Trap IP list. The window will expand downward to show all addresses in the list.</p> <p>To delete an address to the Trap IP List: Select <i>Delete</i> and type the new IP address to be deleted from the read-only Trap IP list.</p>
MIBS	<p>Management Information Base -used to assemble and interpret SNMP messages.</p> <p>The Dataradio Paragon3 MIB is bundled with each unit's firmware. Click "Download mibs.zip" and a pop-up dialog box will appear in your browser asking you to open or save the file to your PC. Save the zip file to a desired location. Unzip the contents of mibs.zip file to a location where your SNMP manager can find it.</p> <p><i>Note: SNMP must be enabled in order for the host PC SNMP manager to work.</i></p>

4.7.3.4.1 NAT on the Base Unit (Paragon3)

When NAT is enabled on the P3, the private network (from the point of view of the Base station) is the IP network associated to the Ethernet 2 interface.




Figure 30 - NAT Enabled on Paragon3




Figure 31 - Paragon3 - Example 1

In example 1, Management Host 1 sends Packet (1) to External Host 1. Since the source IP address of Packet (1) comes from the private network, it gets replaced by the IP address of the Ethernet 1 interface of the Base station.




Figure 32 - Paragon3 - Example 2

In example 2, Management Host 1 sends Packet (1) to Mobile Host 1. Since the source IP address of Packet (1) comes from the private network, it gets replaced by the IP address of the RF interface of the Base station.




Figure 33 - Paragon3 - Example 3

In example 3, Mobile Host 1 sends Packet (1) to External Host 1. Since the source IP address of Packet (1) does not come from the private network, it doesn't get replaced by another IP address by the Base station.




Figure 34 - Paragon3 - Example 4

In example 4, Management Host 1 sends Packet (1) to External Host 1. Even though the packet comes from the private network, the source IP address does not. The Base station does not replace the source IP address of Packet (1).

4.7.3.4.1.1 NAT on the Mobile Unit (GeminiG3)

When NAT is enabled on the Mobile Unit, the private network (from the point of view of the Mobile unit) is the IP network associated to the Ethernet 1 interface.




Figure 35 - NAT Enabled on GeminiG3




Figure 36 - GeminiG3 - Example 1

In example 1, Mobile Host 1 sends Packet (1) to External Host 1. Since the source IP address of Packet (1) comes from the private network, it gets replaced by the IP address of the RF interface of the Mobile unit.




Figure 37 - GeminiG3 - Example 2

In this example, Mobile Host 1 sends Packet (1) to External Host 1. Even though the packet comes from the private network, the IP source address is not part of the private network. The source IP address of Packet (1) does not get replaced by the Mobile unit.

4.7.3.4.2 SNMP Overview

SNMP (Simple Network Management Protocol) is used by network management systems to manage and monitor network-attached devices. SNMP is based on the manager/agent model consisting of a manager, an agent, a database of management information, managed objects, and the network protocol. The manager provides the interface between the human network manager and the management system. The agent provides the interface between the manager and the physical devices being managed (Figure 38). SNMP uses basic messages (*such as GET, GET-NEXT, SET, and TRAP*) to communicate between the manager and the agent.




Figure 38 - SNMP: manager/agent model

4.7.3.4.2.1 MIB

The manager and agent use a Management Information Base (MIB), a logical, hierarchically organized database of network management information. MIB comprises a complete collection of objects used to manage entities in a network. A long numeric tag or object identifier (OID) is used to distinguish each variable uniquely in the MIB and SNMP messages.

4.7.3.4.2.1.1 ParagonP3 MIB File

Each ParagonP3 unit firmware package is bundled with three MIB files (found inside mibs.zip file):

- *dataradio-regs.mib*: contains a top level set of managed object definitions aimed at managing Dataradio products.
- *1213.mib*: contains a set of managed object definitions aimed at managing TCP/IP-based internets.
- *bsc.mib*: contains a set of managed object definitions aimed at managing Dataradio bsc radio base stations.

4.7.3.4.2.1.2 OID

In SNMP, each object has a unique OID consisting of numbers separated by decimal points. These object identifiers naturally form a tree. Figure 39 illustrates this tree-like structure for *1213.mib*, which comes bundled with every ParagonP3 unit package. A path to any object can be easily traced starting from the root (top of the tree). For example, object titled “SNMP” has a unique OID: 1.3.6.1.2.1.11. The MIB associates each OID with a label (e.g. “SNMP”) and various other parameters. When an SNMP manager wants to obtain information on an object, it will assemble a specific message (e.g. GET packet) that includes the OID of the object of interest. If the OID is found, a response packet is assembled and sent back. If the OID is not found, a special error response is sent that identifies the unmanaged object.




Figure 39 - Branch of the 1234.mib OID tree

4.7.3.4.2.1.3 Viewing MIB files

To view the hierarchy of SNMP MIB variables in the form of a tree and view additional information about each node, Dataradio recommends opening all MIB files with a MIB browser. In a MIB browser, each object (*or node*) can be selected and its properties (*including its OID*) can be observed. For simple networks, a basic, free application such as "iReasoning MIB browser" could be used.

However, for managing complex networks, Dataradio recommends a more advanced software application, one capable of browser function as well as being a full-featured SNMP manager, such as the optional "Castle Rock SNMPc Network Manager". Refer to Dataradio Network Management using SNMP User Manual (Part no. 120 47001-nnn for more details).

4.7.3.4.2.1.4 bsc.mib

Figure 40 shows top-level objects of the bsc.mib file:

- *bscIdentity*
- *bscRadioIdentity*
- *bscStatistics*
- *bscDiagnostics*
- *bscControl*
- *bscMobileTable*

These six branches expand into additional branches and leaves. Again, all bsc.mib objects can be accessed through a MIB browser.




Figure 40 - bsc.mib Tree

Note: For more details on Network Management using SNMP refer to Dataradio Network Management using SNMP User Manual (Part no. 120 47001-nnn)

4.7.3.5 Setup (Advanced) ► IP addressing modes

For a description of the broadcast and multicast features of the Paragon3 radio modem, please refer to paragraph 4.7.3.5.1 below.

IP addressing modes

Broadcast

Directed Broadcast ☒ Enabled ☐ Disabled

Limited Broadcast ☐ Enabled ☒ Disabled

Multicast

Multicast Forwarding ☒ Enabled ☐ Disabled

Mobile address 224.168.201.1

Multicast Address List

☐ Add ☐ Delete

Address List Empty

Apply Cancel

Figure 41 - Advanced IP Configuration – IP addressing modes

The IP Addressing web page contains two sections, the one on top controls the forwarding of IP broadcast packets and the other, on the bottom, controls IP multicast packets.

Each section acts independently.

Item		Description
Broadcast	Directed Broadcast	Disabled, Enabled (Default) – Controls forwarding of Directed Broadcast packets
	Limited Broadcast	Disabled (Default), Enabled – Controls forwarding of Limited broadcast packets

Multicast	Multicast	<p>Disabled (Default), Enabled – Controls forwarding of Multicast packets (based on the “Multicast Address List”)</p> <p>Multicast can be used when “one-to-many” communication is required.</p>
	Mobile unit address	<p>This multicast address represents the "All Mobile" group. When a Base station receives an IP packet on its Ethernet interface and the destination IP address matches this multicast address, the IP packet is forwarded over the RF interface to all the Mobile units. The Mobile units will pass this packet to their internal applications.</p>
	Multicast Address List Add / Delete Address	<p>The multicast address list is used to enter multicast addresses for the various "Mobile Hosts" groups. When a Base station receives an IP packet on its Ethernet interface and the destination IP address matches one of these address, the IP packet is forwarded over the RF interface to all the Mobile units.</p> <p>If multicast forwarding is enabled on the Mobile units, the IP packet will be forwarded to the Mobile's Ethernet interface, Mobile Hosts will then be able to receive the packet.</p> <p>The Mobile units have some additional filtering capabilities.</p> <p>To add an address to the Multicast List: Select the “Add” option button and type in the dialog box the new address to be added to the read-only “Address List”. Note that only valid multicast addresses will be accepted and displayed.</p> <p>To delete an address from the Multicast List: Select the “Delete” option button and type in the dialog box the address to be deleted from the “Address List”.</p>
	Address List	<p>Read-only listing. Window expands downward as needed to show all addresses in the list.</p> <p>When an IP packet is received on the Ethernet side of the unit and the destination IP address matches one of the multicast IP addresses in this list, it is forwarded over the RF interface.</p> <p>Remote units will send it over their Ethernet interface.</p>

4.7.3.5.1 IP Broadcast/Multicast Overview

When an IP packet needs to reach more than one unit, the destination address can be set to either a broadcast address or a multicast address.

4.7.3.5.1.1 Broadcasts



Figure 42 - Broadcast Window Detail

There are two types of IP broadcast addresses:

- **Directed broadcast**

A directed broadcast address is an IP address where the host portion is all ones (for instance 172.30.1.255 is the directed broadcast address for the network 172.30.1.0/24, 172.30.1.207 is the directed broadcast address for the network 172.30.1.192/28).

- **Limited broadcast**

The limited broadcast address is 255.255.255.255.

Note:

Routing equipment (to prevent broadcast storms) do not by default forward limited broadcast packets (255.255.255.255). On the other hand, directed broadcast packets are by default forwarded because these packets are routable like any other unicast packets.

4.7.3.5.1.1.1 Directed Broadcast

Each interface of a unit has its own IP address and netmask. From the IP address and netmask, it is easy to calculate the broadcast address associated to the interface. For instance, if the Ethernet interface address of a GeminiG3 radiomodem is 172.30.1.1/24 and the RF interface address is 10.0.1.2/24, then the broadcast address of the Ethernet interface is 172.30.1.255 and the broadcast address of the RF interface is 10.0.1.255.

The “**Directed Broadcast**” option buttons let the user select whether the unit must forward (or not) *directed broadcast* packets. Upon reception of a *directed broadcast* packet, the unit takes the following actions:

If the directed broadcast address matches with one of the unit’s interface broadcast addresses:

- Keep a copy for itself (pass to internal applications, if any).
- If directed broadcast packets can be forwarded (Directed Broadcast is enabled):
Forwards the packet according to the routing table.
- If directed broadcast packets cannot be forwarded (Directed Broadcast is disabled):
Silently discards the packet.

Note:

*Occasionally, the unit cannot determine that the packet is actually a **directed broadcast**. In such a case, the packet is normally routed.*

Example (Directed Broadcast forwarding enabled)




Figure 43 - Example of Directed broadcast forwarding enabled

In this example (Figure 43), directed broadcast forwarding is enabled on the **Base** unit and on **Mobile (1)** unit. If **Sender** wants to reach **Mobile Host (1)**, **Mobile Host (2)** and **Mobile Host (3)** with a single packet, he can send to destination address 172.30.1.255.

Example (Directed Broadcast forwarding disabled)




Figure 44 - Example of Directed broadcast forwarding disabled

In this example (Figure 44), directed broadcast forwarding is enabled on the **Base** unit and disabled on the **Mobile (1)** unit. If **Sender** sends a packet to destination address 172.30.1.255, the packet would be discarded by **Mobile (1)**, it would not reach **Mobile Host (1)**, **Mobile Host (2)** and **Mobile Host (3)**.

If the user wants the **Base** unit to do the discarding of the directed broadcast packets, then the directed broadcast forwarding must be disabled on the **Base** unit itself.

4.7.3.5.1.1.2 Limited Broadcast

The “**Limited Broadcast**” enabled/disabled option buttons control *limited broadcast* packets forwarding. When enabled, the unit forwards *limited broadcast* packets.

Upon reception of a *limited broadcast* packet, the unit takes the following actions:

- Keeps a copy for itself (passes to internal applications, if any).
- If *limited broadcast* packets can be forwarded (Limited Broadcast is enabled):
Sends a copy of the packet out to all the interfaces with the exception of the interface where the packet was received.
- If *limited broadcast* packets cannot be forwarded (Limited Broadcast is disabled):
Silently discards the packet.

Example (Limited Broadcast forwarding enabled)




Figure 45 - Example of Directed broadcast forwarding enabled

In this example, (Figure 45) limited broadcast forwarding is enabled on the **Base** unit and on all **Mobile** units. **If Sender** wants to reach **Mobile Host (1)**, **Mobile Host (2)** and **Mobile Host (3)** and **Mobile Host (4)** with a single packet, he can send to destination address 255.255.255.255.

Notice that **Sender** and **Base** units are on the same LAN (routing equipment does not usually forward limited broadcast packets).

Example (Limited Broadcast forwarding disabled)




Figure 46 - Example of Limited broadcast forwarding disabled

In this example (Figure 46), limited broadcast forwarding is enabled on the **Base** unit, disabled on the **Mobile (1)** unit and enabled on the **Mobile (2)** unit. If **Sender** sends a packet to destination address 255.255.255.255, the packet would reach **Mobile Host (4)** only. The **Mobile (1)** unit would discard any limited broadcast packet it received from the **Base** unit.

If the user wants the **Base** unit to do the discarding of the limited broadcasting packets, then the limited broadcast forwarding must be disabled on the **Base** unit itself. Then no **Mobile Host** unit would ever be receiving a limited broadcast packet.

4.7.3.5.1.2 Multicast

IP multicast addresses are in the range 224.0.0.0 to 239.255.255.255. These addresses are used to represent logical groups of units that may or may not reside on the same networks.

Multicast is used when “one-to-many” communication is required. For instance, a radio station might offer a music channel on the Internet in real time. To receive the music a receiver-host must know the multicast group (multicast address) used by the radio station sender-host and add itself as a member of this group. In the IP realm, a host uses the IGMP protocol to do this. The routers inside the Internet are using IGMP and other multicast routing protocols to build the proper path from the sender to the receivers (a tree-like path is formed from the sender to the receivers).




Figure 47 - Registration to multicast group (First step)




Figure 48 - Reception of multicast packets (Second step)

In the E-DBA environment, an outside sender-host might be interested in sending multicast packets to any one of the following groups:

- “All Mobile” group.
- Various “Mobile Host” groups.

The Base (P3 in the illustration) units are directly connected to the outside network. ALL multicast groups MUST be identified in the Base because the Base unit uses IGMP to register the memberships to the multicast groups on behalf of the other units (Mobile units, Mobile Host units).




Figure 49 - Typical E-DBA Multicast Groups

The following setup example would allow the “Sender” unit to communicate with different multicast groups. The settings shown in Figure 50 below, and also represented in Figure 51, would enable the Sender unit to reach all entities of the various groups.

Multicast	
Multicast Forwarding !	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled
Mobile address !	224.168.201.1
Multicast Address List	
<input type="radio"/> Add <input type="radio"/> Delete !	
Address List	224.168.200.2 224.168.200.1

Figure 50 - Multicast Window Details (On the Base station)

Multicast (Enabled/Disabled)	Enables or disables the registration of the multicast groups by the Base
Mobile address	Indicates the “All Mobile” multicast group
Multicast Address List	Indicates the various “Mobile Host” groups




Figure 51 - Typical E-DBA Multicast Groups (with addresses)

4.7.3.6 Setup (Advanced) ► IP Optimization & Tuning



Figure 52 - Advanced IP Configuration - IP Optimization & Tuning - OIP (Router Mode)

Item	Description
RF ACK	Disabled (Default) - TCP packets are always RF acknowledged regardless of this option setting. Enabled - Use when packets need to be acknowledged at the RF level by the remote unit (destination unit). This option is applicable to all packet types other than TCP.
OIP Retries	Number of OIP retries. Default = 2

4.7.3.7 Setup (Advanced) ► IP Routing

Displays the table of IP routes that are active in the Paragon3 base station.

Typically, display shows routes for RF, ETH1, and ETH2.

IP Routing

Routing Table				
#	Destination Network		Gateway	Type
	IP Address	Netmask	IP Address	
1	172.23.10.0	255.255.255.0	172.23.10.100	Connected
2	172.23.10.100	255.255.255.255	172.23.10.100	Connected
3	192.168.36.0	255.255.255.0	192.168.36.81	Connected
4	192.168.36.81	255.255.255.255	192.168.36.81	Connected
5	192.168.203.0	255.255.255.0	192.168.203.1	Connected
6	192.168.203.1	255.255.255.255	192.168.203.1	Connected

Refresh

Routing Entries

Destination Network		Gateway
IP Address	Netmask	IP Address
<div><div>!</div><div>Add</div><div>Delete</div></div>		

Figure 53 - IP Routing

Item	Description
IP Address	The address portion of the destination network
Netmask	The mask portion of the destination network
Gateway	IP Address: The IP address of the gateway to use when trying to reach the given network
Type	<p>Static: routes added by the user</p> <p>Connected: addresses that are directly reachable by one of the interfaces</p> <p>Proprietary: routes added internally by the Mobile registration process</p>
Add / Delete	<p>Allows the user to add or remove routes manually to/from the table.</p> <p>Warning: Manipulate this table with caution!</p>

4.7.3.8 Setup (Advanced) ► Time Source

To facilitate tracking of events in a network, the Paragon3 base station and the GeminiG3 unit can initialize their real-time clocks using a number of protocols. At reset time, the Paragon3 unit can use the SNTP protocol (RFC2030) to pick up the current UTC (Universal) time. Setting the “TimeZone” and “Daylight Savings” options allows displaying the correct local time in the “Unit Identification and Status” page.

Figure 54 - Advanced IP Configuration – Time Source

SNTP

Client ☒ Enabled ☐ Disabled

Server address 192.168.36.5

Period 3600 Secs

SNTP UTC Time 1194450419

Time Zone

TimeZone (GMT -5:00) Eastern

Daylight Saving ☒ Enabled ☐ Disabled

Apply Cancel

Item		Description
SNTP	Client	Disabled (Default), Enabled
	Server address	IP of the SNTP Server in dot decimal format
	Period	Period at which the SNTP Server is polled
	SNTP UTC Time	SNTP UTC Time Last update received from the SNTP Server (in seconds) - Read-only field.
Time Zone	TimeZone	Select from drop-down list
	Daylight Savings	Disabled (Default), Enabled

4.7.3.9 Setup (Advanced) ► Ethernet (PHY)

The Ethernet port(s) must be configured in a mode that is compatible with the other local devices.

The screenshot shows a configuration window titled "Ethernet (PHY)". It contains two sections: "ETH 1 PHY" and "ETH 2 PHY". Each section has a "PHY Bitrate" setting with three radio button options: "Auto Negotiate", "Force to 100Mbps", and "Force to 10Mbps". Below the bitrate settings is a "PHY Duplex" setting. At the bottom of the window are "Apply" and "Cancel" buttons.

Ethernet (PHY)	
ETH 1 PHY	
PHY Bitrate	<input checked="" type="radio"/> Auto Negotiate <input type="radio"/> Force to 100Mbps <input type="radio"/> Force to 10Mbps
PHY Duplex	Auto Negotiate
ETH 2 PHY	
PHY Bitrate	<input type="radio"/> Auto Negotiate <input type="radio"/> Force to 100Mbps <input checked="" type="radio"/> Force to 10Mbps
PHY Duplex	Half Duplex
<input type="button" value="Apply"/> <input type="button" value="Cancel"/>	

Figure 55 - Advanced IP Configuration – Ethernet (PHY)

Item		Description
ETH1 PHY	PHY Bitrate	Auto Negotiate Force to 100 Mbps Force to 10 Mbps (Default)
	PHY Duplex	Displays factory configured mode of operation: Auto Negotiate
ETH2 PHY	PHY Bitrate	Auto Negotiate Force to 100 Mbps Force to 10 Mbps (Default)
	PHY Duplex	Displays factory configured mode of operation: Half Duplex

4.7.3.10 Setup (Advanced) ► Diagnostic Settings

Diagnostics settings

Analog alarms trap conditions

Analog monitoring rate 500 ms

Chassis power supply <input checked="" type="checkbox"/> goes out of range <input checked="" type="checkbox"/> returns into range Low Threshold 13.0 Volts High threshold 14.5 Volts	Power amplifier power supply <input type="checkbox"/> goes out of range <input type="checkbox"/> returns into range Low Threshold 13.0 Volts High threshold 14.5 Volts
Forward power <input checked="" type="checkbox"/> goes out of range <input checked="" type="checkbox"/> returns into range Low Threshold 0.0 Watts High threshold 0.0 Watts	Standing Wave Ratio <input checked="" type="checkbox"/> goes above <input checked="" type="checkbox"/> returns below Threshold 3.00:1
Analog 1 <input type="checkbox"/> goes out of range <input type="checkbox"/> returns into range Low Threshold 0.0 High threshold 0.0	Analog 2 <input type="checkbox"/> goes out of range <input type="checkbox"/> returns into range Low Threshold 0.0 High threshold 0.0
Chassis temperature <input checked="" type="checkbox"/> goes out of range <input checked="" type="checkbox"/> returns into range Low Threshold 10 °C High threshold 45 °C	

Digital alarms trap conditions

Alarm A1 input <input type="checkbox"/> Asserts <input type="checkbox"/> Unasserts Asserted level is <input type="radio"/> high <input checked="" type="radio"/> low	Alarm A2 input <input type="checkbox"/> Asserts <input type="checkbox"/> Unasserts Asserted level is <input type="radio"/> high <input checked="" type="radio"/> low
Alarm B1 input <input type="checkbox"/> Asserts <input type="checkbox"/> Unasserts Asserted level is <input checked="" type="radio"/> high <input type="radio"/> low	Alarm B2 input <input type="checkbox"/> Asserts <input type="checkbox"/> Unasserts Asserted level is <input checked="" type="radio"/> high <input type="radio"/> low

Forward Power calibration
filename: Bird_45220021_800_F_1.pli
description: Bird 4522-002-1 800MHz FWD PWR \$Revision: 1.4 \$

Reverse Power calibration
filename: Bird_45220021_800_R_1.pli
description: Bird 4522-002-1 800MHz REV PWR \$Revision: 1.4 \$

Analog monitoring 1 calibration
filename:
description:

Analog monitoring 2 calibration
filename:
description:

Figure 56 - Advanced IP Configuration – Diagnostic Settings

Item	Description
Analog alarms trap conditions	
Analog Monitoring Rate	Frequency at which internal values are updated and checked against the alarm boundary conditions. Ranges from 100milliseconds to infinity. Default = 500ms
Analog alarms settings	<p>For each diagnostic value displayed, the user can control alarms trap conditions in the following ways:</p> <ul style="list-style-type: none"> ▪ Set acceptable range of values by entering the low and high thresholds ▪ Choose to be notified when the value goes out of acceptable range by selecting the “goes out of range” check box ▪ Choose to be notified when the value returns into acceptable range by selecting the “returns into range” check box <p>All monitoring combinations are possible</p>
Digital Alarms trap conditions	
Digital Alarms settings	<p>For all digital alarms, the traps can be sent when:</p> <ul style="list-style-type: none"> ▪ “Asserted”-The digital signal changes from low to high ▪ “Unasserted”-The digital signal changes from high to low <p>All monitoring combinations are possible</p>
Calibration Files	
Calibration Files	<p>All Paragon3 unit firmware comes bundled with two interpolation files used for forward and reverse power calibration. These files are required to be used with the optional external power sensor assembly (p/n 030 03547-xxx).</p> <p>Caution: <i>Forward & reverse power readings will not be accurate without the optional external power sensor assembly (p/n 030 03547-xxx). Refer to your Dataradio sales channel for details.</i></p> <p>The file names entered in this section should match the file names in your unit (<i>Note: file names are case sensitive.</i>) These files are needed to properly display the Forward and Reverse power values.</p>

4.7.3.10.1 Calibration Files

Special electrical sensors are used to measure the values of real world quantities such as forward or reverse RF power. These sensors represent all measurements in Volts and require a conversion to proper units where applicable. This conversion is achieved by use of mathematical transfer functions, which also provide a way of calibrating the sensor hardware.

The transfer function can be represented by a simple look-up table that approximates a continuous function by a series of data points. Each data point represents an $\{X_{in}, Y_{out}\}$ pair, where X_{in} is the sensor's output-a measurement in Volts, and Y_{out} is the corresponding value in a desired unit of measurement. Linear interpolation is used to generate Y_{out} values for any given X_{in} value in between the data points supplied in the look-up table.

The series of data points in a look-up table are listed in a text calibration file and is read by the Piecewise Linear Interpolation Calibrated Conversion (PWLICC) software module, employed in Paragon3 radio base station to convert the sensor output into a desired value.

Dataradio supplies look-up tables for forward and reverse power measurements. These tables contain a set of values in Volts (X_{in}) with their corresponding values in Watts (Y_{out}). Similar look-up tables need be created for user-supplied external analog devices connected to the base station's backplane for diagnostics and monitoring if other than voltage measurement units are preferred.

An example of a look-up table is presented in Table 3 with a corresponding graph in Figure 57

Table 3 - Sample Interpolation endpoints

X_{in} (Volts)	Y_{out} (Desired Units)
0.0	0.0
0.2	1.0
0.375	2.0
0.530	3.0
0.530	4.0




Figure 57 - Sample Interpolation curve

Values in-between the data points are calculated using a straight line between the closest two known data points. At least 2 data points are required; however 10 or 20 data points (up to 50) are usually necessary (depending on the curves behavior).

A look-up table can be created with a simple text editor, such as MS-Notepad, carefully following the guidelines presented below. The basic syntax is summarized in Table 3.

- // symbol preceding any entry denotes comments.
- [c] symbol preceding a string of up to 80 characters denotes file description. This string will be displayed under “description” field on the “Diagnostics Settings” page of the Pargon3 web interface.
- [u] symbol preceding a string of up to 15 characters denotes the desired unit of measure.
- [n] symbol preceding an integer denotes the number of entries in the look-up table.
- Data points are filled in as $\{X_{in}, Y_{out}\}$ pairs. Each pair occupies a line and counts *one* space in between its elements:

```
Xin1 Yout1
Xin2 Yout2
Xin3 Yout3
.....
```

- The number of $\{X_{in}, Y_{out}\}$ pairs must correspond to the index ([n]) entered.
- Empty lines are not accepted-use comments for formatting.
- Duplicate X_{in} values are not accepted.
- When complete, use the “Save As” command.

- The file name is case-sensitive and spaces are not allowed.
- The file name should be saved under .pli extension.
- The file should be uploaded into a unit using FTP transfers.
- The file's name should be entered under “Analog monitoring 1 calibration” (and/or “Analog monitoring 2 calibration”) field on the Diagnostic page of the Paragon3 web interface.

Table 4 - PLICC Syntax

Syntax	Description	
// <comment>	Comments.	Optional
[c] <name>	Descriptive name of the look-up table (string of 80 characters max). This field will appear under the “description” field on the Diagnostics Settings” page of the Pargon3 web interface.	Optional
[u] <unit>	Unit of measure (string of 16 char maximum).	Optional
[n] <index>	Number of entries in the table (2 minimum, 50 maximum).	Required

Failure to comply with the guidelines described above may result in the following errors:

Table 5 - Possible Error messages

Error	Description
No file found	The file name entered is not found on the unit.
Bad header or bad file format found.	Syntax Error .
No data found.	No data entered in the file (less than 2 data points).
More than 50 segments found in file.	The file counts more than 50 data points.
Duplicate X values found in data.	The file contains duplicate X_{in} values.

A sample calibration file is presented in Figure 58. Please note the following:

1. “Volts to watts conversion” will appear under the “description” field on the “Diagnostics Settings” page of the Pargon3 web interface.
2. This look-up table contains a set of values in Volts with their corresponding values in Watts.
3. This look-up table contains five data points.
4. The number of data points should correspond to the index (entered under [n]). All X_{in} entries (voltage values) must be unique.


```

// file name: sample_calibration_file.pli
// Revision: N.NN
// Date: YYYY/MM/DD
// Other Comments
[c]Volts to watts conversion
[u]Watts
[n]5
0.000 0.0
0.200 1.0
0.375 2.0
0.530 3.0
0.530 4.0

```

Figure 58 - Sample calibration file

4.7.3.11 Setup (Advanced) ► User Settings



The image shows a 'User Settings' dialog box. It has a title bar 'User Settings'. Inside, there are two sections: 'Temperature Display' and 'Power Unit'. The 'Temperature Display' section has two radio buttons: 'Celsius' (selected) and 'Fahrenheit'. The 'Power Unit' section has two radio buttons: 'Watts' (selected) and 'dBm'. At the bottom, there are 'Apply' and 'Cancel' buttons.

Figure 59 - Advanced IP Configuration - User Settings

Item		Description
Temperature Display	Celsius (default)/Fahrenheit	Select desired temperature scale. Where applicable, the temperature will be displayed in selected temperature scale.
Power Unit	Watts (default)/ dBm	Select desired power scale. Where applicable, the power will be displayed in selected power scale.

4.7.4 Security

4.7.4.1 Security ► Password and Encryption Control

The Setup web pages, the CLI (command line interface) and the FTP server all require a password to prevent unauthorized users from changing a unit's configuration. At the time of manufacture, the password is set to "ADMINISTRATOR" but Dataradio strongly suggests that the password be changed as units are installed.

The screenshot shows a web interface for configuring security settings. It is divided into two main panels: 'User' and 'Encryption'.
The 'User' panel includes:
- 'User ID': A text input field.
- 'Old Password': A text input field.
- 'New Password': A text input field.
- 'New Password (Confirm)': A text input field.
- 'Apply' and 'Cancel' buttons at the bottom.
The 'Encryption' panel includes:
- 'Encryption': A radio button selection with 'Disabled' selected and 'Enabled' as an option.
- 'Encryption Pass Phrase': A text input field containing the word 'Dataradio'.
- 'Encryption Key': A text input field containing the hexadecimal string 'b3 35 b0 7b ba 8d eb 5d 44 66 3c 3a a7 16 f1 80'.
- 'Apply' and 'Cancel' buttons at the bottom.

Figure 60 - Security – Password and Encryption

Item	Description
User ID	Enter a string of any letters or numbers of at least 1 and not exceeding 15 characters <i>The User Name entry is currently not an access-limiting factor. It only serves to identify the person gaining access. User Name may be required by future versions.</i>
Old Password	For an initial installation, enter the default Password ADMINISTRATOR (<i>all upper case letters</i>). For subsequent access, use the Password that you will have configured.
New Password	Enter a string of any letters or numbers of at least 8 and not exceeding 15 characters CAUTION: Do not lose the new password or you will not be able to gain access to the unit; you will need to contact Dataradio for support as detailed in section 1.3 earlier.
New Password (confirm)	Re-enter the new password string
Encryption	Disabled, Enabled (Default)
Encryption Pass Phrase	String of characters used to create a 128-bit AES encryption key. The Pass Phrase can be up to 160 characters long. Using a length of at least 128 characters should provide an adequate security level for most users. <i>A good pass phrase mixes alphabetic and numeric characters, and avoids simple prose and simple names.</i>
Encryption Key	All units in a network must have the same key. <i>READ ONLY - Displayed in pairs separated with spaces</i>

4.7.4.2 Security ► Access Control

Figure 61 - Security - Access List

Item		Description
Access List Control	Access List Control	<p>Access List is used to keep unauthorized unit(s) away from Dataradio RF network. Maximum number of Access List entries = 100.</p> <p>The Access List Control takes the following values:</p> <p>Disabled (Default)</p> <p>Enabled – Authorized units only. Requests from any unit(s) outside this list will be rejected.</p>
Access List Management	Add Entry	Adds entry in the Access Control List
	Delete Entry	Deletes entry in the Access Control List
	Import Access list from file	<p>Imports Access List from file – Populates Access Control table from the file “accesslist.acl”. It is basically a text file that contains a list of RF MAC addresses.</p> <p>E.g.:</p> <pre>0x1234 abcd 2345</pre> <p>where, 0x1234, abcd, and 2345 represent RF MAC addresses in HEX</p> <p>To use this feature:</p> <ul style="list-style-type: none"> -Create a text file “accesslist.acl” with a list of RF MAC addresses -Upload the file from a host PC via an FTP program -Click on “Import Access list from file” button -Click on “Display Access List” button to view the imported access list
	Clear Access List	Clears entire Access Control table
	Display Access List	Clicking this button opens the access list in the message window

4.7.5 Statistics

Statistics web pages allow the user to view data transmission statistics (Interfaces) and base station performance (Channel Utilization).

4.7.5.1 Statistics ► Interfaces

Interfaces			
LAN			
ETH 1		ETH 2	
RX Pkts	8388961	RX Pkts	0
TX Pkts	45138	TX Pkts	0
RF			
OIP sublayer		Airlink sublayer	
RX Pkts	885	RX Ctrl Pkts	887
TX Pkts	0	RX Data Pkts	883
		TX Ctrl Pkts	2546041
		TX Data Pkts	2
Airlink error correction			
Packets with no errors	1770		
Packets corrected	0		
Packets not correctable	0		
Clear (Zero) Interface Stats			

Figure 62 - Statistics – Interfaces

Item		Description
LAN(ETH1)	RX Pkts	Total number of packets received by Ethernet 1 interface
	TX Pkts	Total number of packets transmitted by Ethernet 1 interface
LAN(ETH2)	RX Pkts	Total number of packets received by Ethernet 2 interface
	TX Pkts	Total number of packets transmitted by Ethernet 2 interface
RF	RX Pkts (RF-OIP)	Total number of packets received by RF-OIP interface
	TX Pkts (RF-OIP)	Total number of packets transmitted by RF-OIP interface
	RX Ctrl Pkts (RF-Airlink)	Total number of control packets received by RF-Airlink interface
	RX Data Pkts (RF-Airlink)	Total number of data packets received by RF- Airlink interface
	TX Ctrl Pkts (RF-Airlink)	Total number of control packets transmitted by RF- Airlink interface
	TX Data Pkts (RF-Airlink)	Total number of data packets transmitted by RF- Airlink interface
Airlink error correction	Packets with no error	Number of E-DBA packets, control or data, received over-the-air with zero error.
	Packets corrected	Number of E-DBA packets, control or data, received over-the-air with correctable errors.
	Packets not correctable	Number of E-DBA packets received over-the-air with errors that could not be corrected. These packets were discarded.

4.7.5.1.1 Interface Statistics Conventions

To reduce their design complexity, most networks are organized as a series of layers or levels, each one built upon its predecessor. Layer n on one machine carries on a conversation with layer n on another machine. The rules and conventions used in this conversation are collectively known as the layer n protocol. The number of layers, the name of each layer, the contents of each layer, and the function of each layer differ from network to network.

Figure 63 below illustrates layers and protocols applicable to Dataradio network architecture implementation. The five basic layers are:

- Physical Layer
- Datalink Layer
- Network Layer
- Transport Layer
- Application Layer




Figure 63 - Layers and protocols applicable to Dataradio implementation

In reality, no data are directly transferred from layer n on one machine to layer n on another machine. Instead, each layer passes data and control information to the layer immediately below it, until the lowest layer is reached (Figure 64).

Paragon3 radio base station web interface presents data transmission statistics for the Datalink layer. Network and Transport layers statistics are not accessible through the web interface; they are provided in 1213 MIB and can be accessed through a MIB browser or an SNMP manager (see section 4.7.3.4.2: SNMP Overview for more details on 1213 MIB).




Figure 64 - Layer, protocols, and interfaces applicable to Dataradio implementation

All statistics presented by Dataradio follow a convention presented in Figure 65. Layer n statistics are given with respect to the layer immediately below it: layer $n-1$. RX (Receive) or IN refers to data received by layer n from layer $n-1$. Transmit (TX) or OUT refers to data transmitted by layer n to layer $n-1$.




Figure 65 - RX and TX Convention

4.7.5.1.1 Datalink Layer Statistics

Datalink layer comprises two Ethernet interfaces (Ethernet1 and Ethernet2) and an RF interface. Ethernet1 and Ethernet2 interfaces statistics are illustrated in Figure 66.




Figure 66 - Datalink Ethernet Statistics

RF interface is further subdivided into two sub-layers: OIP sub-layer and Airlink sub-layer. OIP (Optimized IP) sub-layer is concerned with compression, optimization, TCP proxy control, and IP roaming. Airlink sub-layer is where Dataradio's Enhanced Dynamic Bandwidth Allocation (E-DBA) Airlink protocol resides.

RF interface statistics are illustrated in Figure 67. Each E-DBA cycle consists of a fixed number of control packets (e.g.: Requests, Acknowledgements, etc...) and a dynamically allocated number of data packets. This is why both Data and Control packets count appear at the Air link sub-layer.

RF interface statistics also include error correction statistics for all incoming packets. The corrections are accomplished with a forward error correction (FEC) module. The advantage of forward error correction is that retransmission of data can often be avoided.




Figure 67 - Datalink RF Statistics

4.7.5.2 Statistics ► Performance




Figure 68 - Statistics – Channel Utilization

Item	Description
Outbound Data Slot Utilization	<p>The percentage of occupied outbound data slots.</p> $\frac{OccupiedOutboundDataSlots}{OccupiedOutboundDataSlots + EmptyOutboundDataSlots} \times 100$
Inbound Data Slot Utilization	<p>The percentage of occupied inbound data slots.</p> $\frac{OccupiedInboundDataSlots}{OccupiedInboundDataSlots + EmptyInboundDataSlots} \times 100$
Inbound Request Loading	<p>The percentage of air-time available for requests from mobiles in which request packets were actually received, relative to the theoretical maximum for Slotted-ALOHA (36.8% of total capacity). Under certain conditions, this value can exceed 100%.</p>
Occupied Cycle Ratio	<p>The percentage of E-DBA transmit cycles with one or more data packets.</p> $\frac{OccupiedCycles}{EmptyCycles + OccupiedCycles} \times 100$ <p>This value can reach 100% on a light- or medium-loaded system if the number of data packets in each cycle is small (See <i>Occupied Outbound Cycle Average Data Utilization</i>).</p>
Occupied Outbound Cycle Average Data Utilization	<p>The average size of occupied E-DBA transmit cycles, expressed as a percentage of the maximum.</p> $\frac{ActualNumberOfPacketsTransmitted}{MaxOutboundAllocatedNumberOfPackets} \times 100$

4.7.6 Maintenance

4.7.6.1 Maintenance ► Ping Test

To aid in trouble-shooting IP connectivity issues, the Paragon3 base stations and the GeminiG3 mobiles can transmit ping packets to a given IP address. Four packets are sent and the time taken for each to reach the destination and return is displayed.




Figure 69 - Maintenance – Ping Test

Item	Description
Enter IP address	Enter IP address to ping, in dot decimal format
Execute	This button executes the ping command. Ready field displays the outcome of the ping command.

4.7.6.2 Maintenance ► Config Control

Figure 70 - Maintenance -Configuration Control (Initial screen)

Item	Description
Active Configuration Description	Active Configuration Description Field – available by selecting “Checkpoint User Configuration” option button in the “User Configuration Settings “ portion of this window below.
User Configuration Settings	Checkpoint User Configuration (Save User Configuration) – saves a set of the current user configuration settings in the Paragon3 base station. Click on the “Checkpoint User Configuration” option button to activate the “Active Configuration Description” field. Enter a descriptive title of up to 40 characters to help identify the configuration settings to be saved. Click on “Proceed” to save the settings to the unit. The new configuration set overwrites the factory (or previously user saved) configuration settings.
	Restore User Configuration Checkpoint (Load User Configuration) – the option button is available if “User Configuration Settings” have been previously saved. To restore to user configuration, click the “Restore User Configuration” option button. Check the title of the settings about to be restored in the “Active Configuration Description” field and click on “Proceed” to restore the settings to the unit.
Firmware Upgrade Settings	Merge settings bundled in upgrade package with current configuration-merges upgraded settings with the current configuration. Note: the “firmware update” process will end up replacing an existing configuration file with the one that came bundled with the firmware upgrade package.
Factory Settings	Restore Factory Settings: restores all settings do default factory configuration. Upon performing the firmware upgrade, should you decide to restore to factory settings instead of to “merge with bundled settings”, simply select the “Restore Factory Settings” option button right after performing the firmware upgrade and click on “Proceed”. Important note: <i>Activating “Restore Factory Settings” will reset the IP address of the unit. Have your record of all the original Paragon 3 factory settings handy before proceeding with restoring to factory settings.</i>

4.7.6.3 Maintenance ► Package Control

```
200-Package Name: distrib.pkg  
200-Minor: 0  
200-Major: 2  
200 Package distrib.pkg is valid  
Result: PASS
```

Figure 71 - Maintenance – Package Control

Item	Description
Package Control	<p>Used for verifying the field upgrade of the Paragon3 radio modem firmware.</p> <p>The firmware transfer procedure outlined in section 5.5.1 instructs to “Click on Maintenance / Package Control to verify integrity and wait a few moments for the results to display”.</p> <p>Figure 71 above shows a “Pass” result indication.</p> <p>If an upgrade problem arises and persists, click the “Package Control” once more and have the resulting indications handy if contacting Dataradio system engineering.</p>

4.7.6.4 Maintenance ► RF Tests

Test Tones:

Select the desired test tone, press the “Execute” button to transmit a test signal on the channel selected for 20 seconds or until the “Cancel current test” button is pressed.

The functions of all the other buttons are inoperative during test transmissions.

Figure 72 - Control - RF Tests

Test Tones	Modulated	Test transmission generates a carrier modulated with a 1 kHz test tone to check deviations. For specific deviation values, see Table 8 - Carrier Deviations
	Unmodulated	<p>Test tone is an unmodulated carrier that gives a clear carrier and used for checking:</p> <ul style="list-style-type: none"> ◆ Frequency error ◆ Forward and reverse power <p>Power check: Connect an in-line power meter between the radio and the antenna.</p> <p>Measure the forward (nominal 70W) and reflected power levels by pressing the Execute button. For reflected power, never exceed 5% of forward power or as specified by System Engineering.</p>
	100 Hz square wave	Starts a test transmission of a carrier modulated by a square wave. Used to check low-frequency balance at a frequency of 100 Hz
	Random Data	<p>Starts a 20-second test transmission with a carrier modulated with random data. Random data test transmissions are used for checking low-frequency balance and maximum deviation over data.</p> <ul style="list-style-type: none"> • Low-frequency balance check: Helps to determine if the radio transmitter is well balanced for data transmission. Refer to the User manual for values indicated in adjustment tables under “Low Frequency Balance” step. • Maximum deviation check: Helps to verify if the unit is within FCC regulation emission masks. Refer to the User manual for values. <p>Random data test requires the use of an IFR COM-120B service monitor with option 03= 30 kHz IF filter and its DC coupled demodulator output selected.</p>
	Modem deviation calibration	<p>Frequency reprogramming may cause the transmitter deviation to change slightly from that originally set by the factory.</p> <p>The Slope Value control allows the user to adjust the current deviation setting by up to +/- 10%.</p> <p>After selecting a slope value and clicking "Apply", the user should perform a test tone to measure the deviation with a service monitor to assure that it is within governing regulations.</p>

4.7.6.5 Maintenance Feature Options

Refer to your Dataradio technical support or sales representative for options availability and cost.

Available Feature Options		
Option	Description	Status
001	Unrestricted Airlink Speed	ENABLED
002	Medium and Low Airlink Speed	ENABLED
003	COM-1 Serial Port	ENABLED
004	COM-2 Serial Port	ENABLED
005	Ethernet 1	ENABLED
006	Ethernet 2	ENABLED
007	PBSM Diagnostics	ENABLED
008	SNMP	ENABLED
009	FIPS-140	DISABLED

Figure 73- Maintenance – Available Feature Options

4.7.6.6 Maintenance ► RSSI Display




Figure 74 - Maintenance – RSSI Display

Item		Description
RSSI	RSSI Table	Main -120 = dBm value from main radio receiver Diversity -120 = dBm value from diversity radio
	Range	-120 to -40 dBm
	Thresholds	-90 to -60 dBm

4.7.6.7 Maintenance ► System Log




Figure 75 - Maintenance –System Log

Item	Description
System Log	Records critical events resulting from unexpected conditions during the unit operation.
Refresh	Updates the screen to reveal latest log entries.
Erase Log	Deletes all log entries (lost forever). Note: The system log is a limited reserved area of the flash memory. Once full, the new events will not get recorded. It is recommended to clean up this area every so often.

4.7.6.7.1 Reading the Log Entries

The system log records critical events resulting from unexpected conditions during Paragon3 base station operation. Information from this system log can be useful in understanding specific issues. Have the resulting indications handy if contacting Dataradio support.

A system log entry contains the following parts (see Figure 76):

- A record number,
- A time stamp,
- Time in MSec since last unit rest,
- Chassis temperature, and
- The event itself




Figure 76 - A system Log Entry

Note:

Log information will be preserved across system restarts or faults.

The general categories of events that can be found in the system log are:

- Asserts: undesirable conditions (faults)
- Resets: reasons for various system resets
- Others: warnings, recovery from a fault, etc

4.7.6.7.1.1 Asserts

An Assert log entry will normally display an exit code, a module number, and a line number indicating where the error occurred. See Figure 77 for an example of an Assert log entry. This information will allow Dataradio support team to determine the component and the reason of an error so that a corrective action could be recommended.

```
[56 1970-01-04 04:39:28 275949.382 43°C]
Exit... 0x2a00b6 (MODULE 42 LINE 182)
```

Exit Code Module Number Line Number

Figure 77 - An Assert type system log entry

Note:

“0x0” exit code signifies normal (non-faulty) system exit.

4.7.6.7.1.2 Resets

A Paragon3 unit may be reset manually (through the Web interface, a telnet shell, or SNMP control) or automatically (as a result of the unit’s own monitoring facilities).

Below are some examples of Reset log entries:

Reset issued by a shell command:

```
[5 1970-01-01 01:03:45 3827.924 37 C]
stationReset: board hard reset
```

Reset issued through the WEB Interface:

```
[10 1970-01-10 21:49:00 856116.827 38 C]
HTTP server reset
[11 1970-01-10 21:49:00 856116.842 38 C]
Exit... 0x0
```

Reset issued by an SNMP MIB browser:

```
[14 2007-09-17 16:25:17 631.641 34 C]
SNMP: board hard reset
```

Reset issued by the DSP service (automatic):

```
[10 1970-01-05 01:11:33 1114813.668 36°C]
Master unit: stationreset on DSP flow control events
[11 1970-01-05 01:11:34 1114813.954 36°C]
Exit... 0x0
```

4.7.6.7.1.3 Other

Below are some examples of other log entries. They may be warnings, faults on temporary conditions that can later be recovered, recovery from faults, or other abnormal conditions worth mentioning.

Recovery from a fault:

```
[96 1970-01-29 20:13:06 2504357.930 46°C]
Fault: cleared old fault level: 0
```

A new fault condition being reported:

```
[112 2007-05-23 15:35:59 1826879.484 44°C]
Fault: new fault level: 1 : DSP Driver Error 2: _DSP_READY line hung up..
```

Abnormal conditions worth mentioning:

```
[113 2007-05-24 11:19:19 1897872.968 46°C]
OIP2LLC::FlowControl:qid=357,mcnt=32,tout=360100

[114 2007-05-24 11:25:19 1898233.59 46°C]
OIP2LLC::FlowControl:qid=357,mcnt=32,tout=360100

[115 2007-05-24 11:31:19 1898593.154 46°C]
OIP2LLC::FlowControl:qid=357,mcnt=32,tout=360100
```

4.7.6.8 OOB Data ► Out of Band (GPS delivery)

Figure 78 - Out-Of-Band

Item		Description
GPS Delivery	Delivery Options	Drop-down box for selecting the desired format for the Local Port GPS data delivery
	UDP Hosts	Dynamic window expands as Hosts are added or shrinks as Hosts are deleted. (Screen capture shows one UDP Host added – displayed as #1)
	Add/Delete UDP Host	Up to five UDP Hosts may be added: <ul style="list-style-type: none"> ◆ Select the Add or the Delete option button. ◆ Enter dot decimal format address of the Host in the address field box. ◆ Enter port number in the Port field box. ◆ Click on the “Format” drop-down box and select appropriate format for the UDP Host being added or deleted. ◆ Click on Apply.

4.7.7 Remote Table

Remote Table
Active Mobiles: 1

#	RF MAC	RF IP Addr	Proxy	Status	Reg'd	Last TX	Tx Pkts	Tx Retrys	Tx Bytes	Last RX	Rx Pkts	Rx Bytes	P3 RSSI dBm	G3 RSSI dBm	Local upgrade revision	Remote upgrade revision	Last GPS Report UTC Latitude Longitude
1	00027C	172.23.10.1	On	Normal	14:36:51	14:36:52	1	0	41	14:36:51	0	0	-123	-60	0	0	15:10:41 45°29.7244N 073°39.8598W

Mobiles per page (25 maximum):

Figure 79 - Remote Table

Item	Description
#	Index of the displayed entry. Up to 25 entries will be displayed at a time. "Previous" and "Next" buttons will appear as necessary.
RF MAC	RF MAC address of the mobile
RF IP addr	RF IP address of the mobile
Proxy	Indicates when the TCP Proxy has been enabled for that mobile (On/Off)
Status	Indicates the current state of the mobile. Most common values are: <ul style="list-style-type: none"> ♦ Normal – Mobile is registered to this base ♦ Handoff – Mobile is roaming to another base
Reg'd	Indicates the time the mobile registered on the base
Last TX	Indicates the time of last transmitted packet
TX Pkts	Count of data packets sent to the mobile
Tx Retrys	Count of RETRYs for packets transmitted to the mobile
Tx Bytes	Count of bytes transmitted to the mobile
Last Rx	Indicates the time of the last received packet
Rx Pkts	Count of data packets received from the mobile
Rx Bytes	Count of bytes received from the mobile
P3 RSSI dBm	RSSI (in dBm) of the last data received from the mobile.
G3 RSSI dBm	RSSI (in dBm) of a recent data from the base by the mobile (This information is transmitted to the base along with the GPS report)
Local upgrade revision	Number of local updates (incremented when updated locally)
Remote upgrade revision	Number of remote parameter updates (incremented when updated over the air)
Last GPS Report: <ul style="list-style-type: none"> ♦ UTC ♦ Latitude ♦ Longitude 	In normal operation, indicates the last Time & Position reports recently transmitted to the base from the mobile. Indicates "GPS report missing or not valid" when originally registered if reporting has not yet begun. Could last up to 3 – 4 minutes. Indicates "No Fix" when validly reporting and stops receiving valid information.

4.7.8 Help

Site Map link and Help icon (Figure 80) features are designed to help the user navigate through the Web-Pages. They can be found on the bottom of the navigation pane.



Figure 80 - Help Icon

Item	Description
Site Map	Click Site Map link to display a page that hierarchically lists all Web-Pages on the site and provides a short description where applicable.
Help Icon	Click the Help Icon in the navigation pane to open a help text relating to the window being displayed.

5. Trouble-Shooting and Testing

The checks described below should be done at time of installation, annual intervals, or whenever deterioration in performance is noted.

5.1 Equipment Required

- In-line wattmeter (10 W range) for the 5W-transmitter module as well as for the reflected power and (150W range) for the power amplifier.
- Radio service monitor (IFR-120B with option 03: 30 kHz IF filter or equivalent).
- RG-214 or RG-223 cable with N-Type male connector to connect Paragon3 base station to the service monitor.

Important note: Before proceeding make sure that the service monitor has been calibrated recently and has warmed up for at least the time specified by its manufacturer.

Some reported frequency and deviation problems have actually been erroneous indications from service monitors that have not adequately warmed up. This is particularly likely when field service is done during winter months.

5.2 Recommended Checks

A) After an installation

1. Power-up LED Sequence
2. Transmit power output
3. Reflected power output
4. RF Link test between Paragon3 unit and mobile unit(s) (PING test from the unit's Web page as per paragraph 4.7.6.1 or PING from a PC as per paragraph 5.4.1)

B) For annual maintenance & trouble-shooting

Same checks as A) plus:

5. Carrier frequency error
6. TX Deviation
7. Low frequency balance
8. 12dB SINAD
9. Receiver distortion
10. Main RX and Aux. RX RSSI
11. Verify power supply connections & terminals torque settings (see paragraph 2.5.1.1)

Table 6 - Checklist A (After installation)

CHECKLIST A (Paragon3) Recommended Check out after Installation				
Step	ACTION	EXPECTED RESULTS at 25°C	MEASURE WITH	IF NOT?
1	Normal Power-up Sequence	PWR LED lights red for four second, turns amber for one second, and stays green thereafter. TX LED flashes green once about fifteen seconds after power-up then keeps flashing in-tune to the cycle marker RX LED remains OFF STATUS LED remains OFF ETH 1 LED – if connection present – lights green. Flashes amber with activity ETH 2 LED – If connection present – lights green. Flashes amber with activity		
	BSC			
	RX1 and RX2	SUPPLY LED must remain steady green		
	Transmitter	SUPPLY LED must remain steady green ON LED lights red for one second, turns OFF for 10 seconds, and stays red thereafter		
For steps below, refer to Radio (RF Tests) WebPage				
2	Power Amplifier Output Power Under Test Tone section select Unmodulated and press “Execute”	UHF: 100 watts 800 MHz: 70 watts (user settable from 20W) Tolerance: +15% -20%	Service monitor set to read power or 150W in-line wattmeter installed as close as possible to the unit antenna connector.	¹ Check for bad connections, damaged coax cable, etc.
3	Transmitter Reflected Power Under Test Tone section select Unmodulated and press “Execute”	< 5% of forward power or as specified by System Engineering.	10W in-line wattmeter	Check for bad connections, damaged coax cable, etc.
4	RF Link test between Paragon3 unit(s) and mobile unit(s) (PING test from the unit Web page as per paragraph 4.7.6.1 or PING from a PC as per paragraph 5.4.1)			

¹ (unless unit has been set a lower value). Note that readings less than 100 watts for UHF or 70 watts for 800 MHz models, may be due to losses in cables used for testing. Check also your wattmeter frequency calibration curve. Do not be too ready to condemn the transmitter or the RF feedline & antenna installation.

Table 7 - Checklist B (General)

CHECKLIST B (Paragon3) General Check out (part1 of 2)				
<p>Paragon3 units are set and characterized at the factory to optimize performances. It is not recommended to try readjusting units unless it is really required. Misadjusting a unit may result in significant performance losses.</p> <p>The proposed adjustments in the "IF NOT?" column below, should be tried ONLY if system data performance degradation is noticed combined with out-of-tolerance items.</p>				
Step	ACTION	Expected Results at 25°C	MEASURE WITH	IF NOT?
1	Normal Power-up Sequence	PWR LED lights red for four second, turns amber for one second, and stays green thereafter. TX LED flashes green once about fifteen seconds after power-up then keeps flashing in-tune to the cycle marker RX LED remains OFF STATUS LED remains OFF ETH 1 LED – if connection present – lights green. Flashes amber with activity ETH 2 LED – If connection present – lights green. Flashes amber with activity		
	BSC			
	RX1 and RX2	SUPPLY LED remains steady green		
	Transmitter	SUPPLY LED remains steady green ON LED lights red for one second, turns OFF for 10 seconds, and stays red thereafter		
For steps below, on the Radio → Set Up Web page, press the “test” button to enable Test Tone function				
2	Transmitter Output Power From the Maintenance unit WEB “Test Tone” page, Select Unmodulated – Press Execute	UHF: 100 watts 800 MHz: 70 watts (user settable from 20W) Tolerance: +15% -20%	Service monitor set to read power or 150W in-line wattmeter installed as close as possible to the unit antenna connector.	Adjust “Power” on the “Power Amp” front panel (see Figure 7)
3	Transmitter Reflected Power Under Test Tone section select Unmodulated and press “Execute”.	< 5% of forward power or as specified by System Engineering.	10 W in-line wattmeter	Check for bad connections, damaged coax cable, etc.
4	RF Link test between Paragon3 unit and mobile unit(s) (PING test from the unit Web page as per paragraph 4.7.6.1 or PING from a PC as per paragraph 5.4.1)			
5	Carrier Frequency Error Under Test Tone section select Unmodulated and press “Execute”.	< ±300 Hz @ 25°C ambient or < ±1 ppm from –30 to +60 °C	Service monitor set to read frequency error	Adjust TCXO (IC700) (inside Exciter module at, Figure 91 (800) and Figure 93 (UHF),
6	TX Deviation (kHz) Under Test Tone section select Unmodulated and press “Execute”. Carrier will be modulated with a 1 kHz tone.	Refer to 5.3.1 for TX Deviation details. Tolerance is +5%, -10% for all bit rates.	Service monitor set to read deviation. (IF filter set to Mid or 30 kHz position)	If transmitter is re-tuned outside its original factory-calibrated tuning range or where its deviation readings are found to be out-of-specs, please contact Dataradio System Engineering.

CHECKLIST B (Paragon3) cont'd General Check out (part 2 of 2)				
Step	ACTION	Expected Results at 25°C	MEASURE WITH	IF NOT?
7	Low Frequency Balance Under Test Tone section select Random Data and press "Execute"/	a) Record deviation level read from step 6 b) Record deviation read from <i>TX Random test</i> c) Difference between a) and b) should be: < 2.5 kHz	Service monitor set to read deviation (IF filter set to Mid or 30 kHz position, all audio filtering disabled)	Refer to Section 6.2.3.4
8	12 dB SINAD (Dataradio wide band measurement method: no audio filtering) Set TX deviation to ± 3 kHz.	Better than -108 dBm including cable loss (Typically -109 to -110 dBm)	- Backplane corresponding to the receiver being verified: J1 (RX1) or J5 (RX2), Pin 6 (see Figure 3) - Service monitor (IFR) set to SINAD IFR IF filter set to MID position or 30 kHz wide filter.	Refer to section 6.2.2.4
9	Receiver distortion (Dataradio wide band measurement method: no audio filtering) - Set service monitor RF Gen output to -70 dBm Deviation level as per SINAD above.	≤ 5.5 % (Typically < 3.5 %)	- Backplane corresponding to the receiver being verified: J1 (RX1) or J5 (RX2), Pin 6 (see Figure 3) - Service monitor (IFR) set to DISTORTION. - IFR IF filter set to MID position or 30 kHz wide filter.	
10	RSSI Apply to each receiver input the following RF level: UHF & 800: -110dBm	UHF & 800 MHz: 2.0 VDC (+/- 0.3VDC) BSC must be connected to the radio during the measurements	- Backplane corresponding to the receiver being verified: - J1 (RX1) or J5 (RX2), Pin 5 (see Figure 3) - DC Voltmeter measurement	Refer to section 6.2.2.5 for all models. Refer to factory technical support only if RX data performance degradation is noticed combined with out-of-tolerance RSSI readings.
11	Verify power supply connections & terminals torque settings (see paragraph 2.5.1.1)			

5.3 Additional test details

5.3.1 Carrier Deviations

Table 8 - Carrier Deviations

Carrier Modulation					
SRRC4FSK		SRRC8FSK		SRRC16FSK	
			Tone		Tone
Network Speed (kb/s)	Typical deviation in kHz (1000Hz test tone)	Network Speed (kb/s)	Typical deviation in kHz (1000Hz test tone)	Network Speed (kb/s)	Typical deviation in kHz (1000Hz test tone)
25 kHz Channel (UHF)					
32.0	± 3.7	48.0	± 4.0	64.0	± 4.1
		43.2	± 4.2		
12.5 kHz Channel (UHF)					
16.0	± 1.7	24.0	± 2.0	32.0	± 2.1
25 kHz Channel (800 MHz)					
32.0	± 2.4	48.0	± 2.7	64.0	± 2.9
		43.2	± 3.3		
NPSPAC Channel (USA – 800 MHz)					
16.0	± 2.4	24.0	± 2.7	32.0	± 2.9

5.3.2 PF Switch

Nearly all test “Actions” described in tables 5 and 6 above can be done by selecting the relevant test tone via the “Radio ► Tests” page of the web interface. However, stopping the Airlink for a test is done in a different manner. It requires the use of the BSC’s front-mounted PF key rocker switch (*see Figure 8 - BSC module above and detailed PF operation in the next paragraph*). The PF switch can also be used as an alternate way of selecting Test Tones or if a web connection is unavailable.

5.3.2.1 Stopping the Airlink and Alternate Test Tone Selection Method

Located on the BSC module, the PF key is a horizontally mounted rocker switch with a center detent and spring-loaded positions “1” and “2”. Pressing the switch to position “1” causes the “Status” LED to blink green once only followed by amber blinks at one-second intervals as long as it is held pressed. Pressing the switch to position “2” is used to select test tones as shown in Table 9 below.



Figure 81 - PF Switch Rocker Detail (one side pressed)

- If PF is pressed to position “1” for approximately four seconds (*visually count the amber blinks*) and released, it brings the Airlink down, PTT is released, no data traffic is scheduled, and CWID is suppressed. The Airlink will remain down for a maximum of one hour and automatically come back up, unless PF is pressed to position “1” once more for four seconds to force toggle the Airlink to “up” status.
- If PF is pressed to position “1” for approximately one amber blink, PF operation goes into “monitor mode” where “position 2” is monitored and each successive pressing of position “2” results in a different test tone selection as detailed in the table below.
- If PF is pressed to position “1” while a test is in progress, PF “monitor mode” operation is cancelled.

Note:

If PF is not in “monitor mode” pressing to position “2” has no effect.

Table 9 – Test Tones Generation

20-Second Test Tones - PF key generated
For a MODULATED test tone: Press PF to “1” for approximately 1 amber blink and release. Immediately press PF to “2” one time. Test tone starts. To cancel test tone, press PF to “1” and release.
For an UNMODULATED test tone: Press PF to “1” for approximately 1 amber blink and release. Immediately press PF to “2” two times. Test tone starts. To cancel test tone, press PF to “1” and release.
For a SQUARE WAVE test tone: Press PF to “1” for approximately 1 amber blink and release. Immediately press PF to “2” three times. Test tone starts. To cancel test tone, press PF to “1” and release.
For a RANDOM DATA test tone: Press PF to “1” for approximately 1 amber blink and release. Immediately press PF to “2” four times. Test tone starts. To cancel test tone, press PF to “1” and release.

Each pressing at position “2” must be made within one second.

E.g.: For Unmodulated, press twice within 2 seconds, for Random Data, press four times within 4 seconds.

5.4 Windows/Unix Tools

5.4.1 Network Connectivity

- PING (DOS/WINDOWS)

The `ping` command determines whether a specific IP address is accessible. It works by sending a packet to the specified address and waiting for a reply. It is useful for troubleshooting “end-to-end” reachability, network connectivity, and network latency.

The ping test is also convenient to verify more specifically the RF link between a mobile and a known base station

Available for MS-Windows 9x, ME, NT, 2000, and XP as well as Unix & Free BSD.

EXAMPLE:

`ping 192.168.204.1 -w 3000` displays the response with turn around time in milliseconds.

- TRACERT (WINDOWS)

The `tracert` command is used to visually see a network packet being sent and received and the amount of hops required for that packet to get to its destination.

Available for MS-DOS 6.2, MS-Windows 9x, ME, NT, 2000, and XP.

Note:

Users with MS-Windows 2000 or XP who need additional information on network latency and network loss may also use the `pathping` command.

EXAMPLE

`tracert www.yahoo.com` at the command prompt displays the intermediate routers between local host to the `www.yahoo.com` site.

5.4.2 Configuration Information

- WINIPCFG (WIN95/98), IPCONFIG (WIN2K) or IFCONFIG (UNIX)

`Ipconfig` is a DOS utility which can be used from MS-DOS or a MS-DOS shell to display the network settings currently assigned and given by a network. This command can be utilized to verify a network connection as well as to verify network settings.

Available for MS-DOS, MS-Windows 9x, ME, NT, 2000, and XP.

EXAMPLE

`ipconfig/all` at the command prompt displays the Ethernet MAC address, IP address, IP netmask, default IP gateway, DNS server... information.

- ARP

View and update the system ARP table

The Address Resolution Protocol (ARP) is used with the IP protocol for mapping a 32-bit Internet Protocol address to a MAC address that is recognized in the local network specified in RFC 826. Once recognized the server or networking device returns a response containing the required address.

Available for MS-Windows 9x, ME, NT, 2000, and XP.

EXAMPLE

`arp-a` displays all entries in the ARP cache. *Useful in manipulating ARP caches.*

- **ROUTE**

View and update the system routing table

The function and syntax of the Windows ROUTE command is similar to the UNIX or Linux route command. Use the command to manually configure the routes in the routing table.

Available for MS-Windows 9x, ME, NT, 2000, and XP.

EXAMPLE

route ? displays help

route print displays the routing table

5.4.3 Statistics Information

- **NETSTAT (WINS & UNIX)**

The netstat command symbolically displays the contents of various network-related data structures, i.e. IP, TCP UDP ...

Available for MS-Windows 9x, ME, NT, 2000, and XP.

EXAMPLE

netstat ? displays help

netstat -a display TCP and UDP connections and listening ports information

For further information on TCP/IP troubleshooting, please visit:

<http://www.windowstlibrary.com/Content/466/14/1.html>

5.5 BSC Firmware Upgrading

The Paragon3 radiomodem firmware is field-upgradable using the unit's Ethernet port. The process involves connecting to the IP address of the base from a host PC and transferring the firmware files via an FTP program.

5.5.1 Procedure

1. Using a file decompression program, such as WinZIP™ or WinXP's right-click & select the "Expand to..." option, expand the contents of the firmware upgrade package to a directory of your choice on the host PC.

Warning:

Be aware that base and mobile's firmware archives are often distributed at the same time. Files intended for the Paragon3 radiomodem are labeled in the form

Paragon3_edba_Vx.x_Rx.xx.zip. Be careful not to transfer firmware into the wrong unit!

2. Using an FTP client program of your choice, establish a connection to the base IP address. Please refer to paragraph 4.7.4.1 for "Username" and "Password" usage.
3. Transfer all the files in the upgrade package. Occasionally, long pauses, on the order of 30 to 45 seconds, are possible when storing the file in the unit's flash file system.
4. Once the file transfer is complete, cycle the base power and allow the unit to boot. The unit should return to the state it was in when the update was started.

Note:

After resetting, the PWR LED remaining lit steady amber or red indicates the FTP transfer was not successful or that the firmware is corrupt. Please contact Dataradio system engineering for assistance.

5. Verify the integrity of the newly transferred files.
 - a) Connect to the base's IP address using an Internet browser such as IE (5.0 or later) or Mozilla.
 - b) Enter the user name and password (*in the usual manner*) and allow the **Welcome** page to load.
 - c) In the left pane, click on **Unit Status**. The **Unit Identification and Status** pane should display the newly upgraded firmware in its **Banner** (*should correspond to the upgrade package version*) and the **H/W Status** should also show **Ok**.
 - d) In the left pane, click on **Maintenance**, then on **Package Control**. Wait a few moments for the results to display. Figure 71 shows a "Pass" result indication.




Figure 82 - Sample FTP program

5.5.1.1 File Integrity Failure

If the message in the result screen points out that file(s) failed the integrity check, retry the FTP transfer for the failed files(s) again.

If the problem persists, please have the **Package Control** result screen indications handy and contact Dataradio system engineering for assistance.

6. Radio Programming and Adjustments

All receiver procedures detailed in this section should be done twice: once for the “Main” (or RX1) receiver module and a second time for the “Auxiliary” (or RX2) receiver module. Connect to the relevant module and its corresponding backplane PCB as required.

6.1 Series II Radio Programming

This procedure describes the steps needed to program the UHF and 800MHz Paragon3 stations.

6.1.1 Recommended Items

- Pentium II PC or better, MS-Windows 98-SP2 or later if not using LAN card, MS-Windows 2000-SP4 if using a local network (or Windows XP-SP2)
- T800win programming kit for Series II:
- PGM800Win programming software user's manual
- PGM800Win Windows based programming software version 3.0 or later
- T800-01-0002 programming cable (DB-25 to RJ-45 cable)
- Standard 25-pin parallel cable (terminated Male/Female)

6.1.2 Module Programming

Before starting programming, have a PC running MS-Windows © and the Tait PGM800Win software for Series II Base station.

This program supports the use of a mouse but may be used without one if required. Keyboard access follows the conventional MS-Windows © method as briefly described below:

- Press and hold the “Alt” key while pressing at the same time the relevant hotkey as indicated by an underlined letter on the menu command.
 - On a drop-down menu, press only the hotkey without pressing the “Alt” key.
 - Use the “Tab” key to cycle available fields and the “Enter” key to validate entries. *e.g. Pressing “Alt”+F opens the File drop-down menu and pressing “A” opens the Save As directory service box.*
 - **Receiver VCO and front-end alignment** will be required when new receiver frequency is programmed outside the radio tuning range:
 - 800 = ± 3.0 MHz from previous center frequency
 - UHF = ± 2.5 MHz from previous center frequency.
 - **Exciter and PA alignment** will be required when new transmitter frequency is programmed outside the radio tuning range: ± 4 MHz from previous center frequency.
1. Connect the PC, via the supplied programming lead, to the speaker panel’s front-mounted RJ11 connector.
 2. Run Tait PGM800Win program and follow instructions found in the T800 Programming Software User’s Manual to select the proper module to be programmed.
 3. When setting channel's frequencies
 - Do not program any CTCSS tones on channels.
 - Do not change any other parameters.
 - Refer to Figure 83, Figure 84, Figure 85 and Figure 86 for screen program examples.
 4. Save the base station programming info to a file for further reference.
 5. To permanently save your changes into the radio module, click “Write”.

PGM800Win - T800 Programming Application

File View Communication Window Help

Model: T885-10-0000 Serial Number: 13111997

System Information

[T885-10-0000]

Serial Number: 13111997 Lower Frequency Limit [MHz]: 800.000000

Custom Model: Upper Frequency Limit [MHz]: 870.000000

Standard Model: T885-10-0000 Injection side: Low

Module Type: Receiver Intermediate Frequency (MHz): 45.0

Last Modified: 15-09-2005

Firmware SW: V01.01

Remark: NEXT GEN RX2

Close Save Write Edit Default Chan Delete

Figure 83 - Receiver System Information Sample

PGM800Win - T800 Programming Application

File View Communication Window Help

Model: T885-10-0000 Serial Number: 13111997

Channel Information

Default Channel

Chan Frequency MHz CTCSS PIN 8-1 Switch

1 812.200000 0 11111111 11111110

Channel information Default: [1]

Channel	Frequency (MHz)	CTCSS (Hz)	Pin 8	Pin 7	Pin 6	Pin 5	Pin 4	Pin 3	Pin 2	Pin 1	Switch Setting
0	0.000000	0.0	Low	Low	Low	Low	Low	Low	Low	Low	11111111
1 DC	812.200000	0.0	High	High	High	High	High	High	High	High	11111110
2	813.200000	0.0	High	High	High	High	High	High	High	High	11111101
3	814.000000	0.0	High	High	High	High	High	High	High	High	11111100
4	0.000000	0.0	High	High	High	High	High	High	High	High	11111011
5	0.000000	0.0	High	High	High	High	High	High	High	High	11111010
6	0.000000	0.0	High	High	High	High	High	High	High	High	11111001
7	0.000000	0.0	High	High	High	High	High	High	High	High	11111000
8	0.000000	0.0	High	High	High	High	High	High	High	High	11110111
9	0.000000	0.0	High	High	High	High	High	High	High	High	11110110
10	0.000000	0.0	High	High	High	High	High	High	High	High	11110101

Close Save Write Edit Default Chan Delete

Figure 84 - Receiver Channel Information Sample

PGM800Win - T800 Programming Application

File View Communication Window Help

Model: T881-10-0000 Serial Number: 13135194

System Information

[T881-10-0000]

Serial Number: 13135194 Lower Frequency Limit [MHz]: 800.000000

Custom Model: Upper Frequency Limit [MHz]: 870.000000

Standard Model: T881-10-0000 Transmit timeout timer (sec): 0

Module Type: Transmitter Transmit lockout timer (sec): 0

Last Modified: 28-02-2006 Transmit tail timer (sec): 0.00

Firmware SW: V01.01

Remark:

Close Save Write Edit Default Chan Delete EPOTS

Figure 85 - Exciter System Information Sample

PGM800Win - T800 Programming Application

File View Communication Window Help

Model: T881-10-0000 Serial Number: 13135194

Channel Information

Default Channel

Chan	Frequency MHz	CTCSS	Deviation	Reference	PIN 8-1	Switch
0	0.000000	0	0	0	00000000	11111111

Channel information Default: [0]

Channel	Frequency [MHz]	CTCSS [Hz]	Deviation	Reference Modulation	Pin 8	Pin 7	Pin 6	Pin 5	Pin 4	Pin 3	Pin 2	Pin 1	Switch Setting
1	0.000000	0.0	0	0	High	High	High	High	High	High	High	High	11111110
2	796.000000	0.0	0	181	High	High	High	High	High	High	High	High	11111101
3	800.000000	0.0	0	176	High	High	High	High	High	High	High	High	11111100
4	0.000000	0.0	0	0	High	High	High	High	High	High	High	High	11111011
5	0.000000	0.0	0	0	High	High	High	High	High	High	High	High	11111010
6	0.000000	0.0	0	0	High	High	High	High	High	High	High	High	11111001
7	0.000000	0.0	0	0	High	High	High	High	High	High	High	High	11111000
8	0.000000	0.0	0	0	High	High	High	High	High	High	High	High	11110111
9	0.000000	0.0	0	0	High	High	High	High	High	High	High	High	11110110
10	0.000000	0.0	0	0	High	High	High	High	High	High	High	High	11110101
11	0.000000	0.0	0	0	High	High	High	High	High	High	High	High	11110100

Close Save Write Edit Default Chan Delete EPOTS

Figure 86 - Exciter Channel Information Sample

6.1.3 Channel Selection via DIP Switches

The backplane-mounted DIPswitch settings override the default channel programmed by PGM800Win.

To set a default channel via the software, all DIPswitches must be set to “OFF” (i.e. 0000).

When a switch is “Off”, its binary count is active; when a switch is “ON” its binary count is inactive. The various DIPswitch combinations of ON or OFF make up a binary total, which identifies the channel number.

To select a channel, set the appropriate DIPswitch or switches to “OFF” to make the binary count total the channel number you want. Set all other switches to “ON”.

Example: To select channel 5, set the DIPswitches as shown below:




Figure 87 - Backplane DIP switches example - Channel 5 selected

6.2 Series II Radio Tuning

This section covers some basic Series II base station modules radio tuning and verification for:

- UHF (T85x-xx-0250) and
- 800 MHz (T88x-xx-0200).

Note: Usually, this section is never done unless called for in section 6.1 “Series II - Radio Programming” or in Table 7 “Checklist B” (General).

To identify the radio modules, check the part number on the manufacturer’s label at the back of the Receiver, Exciter, and Power Amplifier modules:

RX	TX	PA
T885-10-0200 (800-870 MHz, 25kHz)	T881-1x-0200 (800-870 MHz)	T889-10 (850-870 MHz)
T855-10-0250 (400 - 440 MHz, 25kHz)	T857-1x-0250 (400 - 440 MHz)	T859-10-0000 (400 - 440 MHz)
T855-20-0250 (440 - 480 MHz, 25kHz)	T857-2x-0250 (440 - 480 MHz)	T859-20-0000 (440 - 480 MHz)
T855-30-0250 (480 - 530 MHz, 25kHz)	T857-3x-0250 (480 - 520 MHz)	T859-30-0000 (480 -520 MHz)

6.2.1 Test Equipment

- Digital Multimeter & probes (e.g. Fluke 77)
- 1 HP 34330A Shunt 30A (UHF only, used for transmitter current measurement)
- Digital or Analog calibrated Oscilloscope & scope probes (X1, X10 selectable)
- Calibrated COM-120B (.001ppm OCXO and 30kHz IF options)
- 3-foot length of double-shielded N-M to BNC-M cable (RG-214 or RG-223)
- 2x 'BNC' to 'N' type adapters (e.g. Amphenol, Greenpar).
- Bird RF power meter with 150W / 50 ohm dummy load (optional)
- 3dB 150-watt attenuator
- 1x Torx screwdriver #T-10 and #T-20
- Pozidriv screwdriver #1 & #2
- 1x Six-inch adjustable wrench
- RF tuning/trimming tools.
- Extender Rail Kit for Series II chassis (T800-13-0000)
- 1x 18" coax cable N-M to BNC-M (comes with the radio to connect the exciter to the PA)

6.2.2 Receiver module (T885-xx-0200, T855-xx-0250)

Note 1: Refer to Figure 90 (T885) and Figure 92 (T855) for locating tuning controls.

Note 2: When the synthesizer is unlocked, the front panel green LED called "Supply" will flash indicating that it needs re-tuning.

Warning,

The LED will also flash when the unit is in setup mode while connected to the PGM800win program.

6.2.2.1 Initial Setup

This initial setup will be used during all receiver alignment procedures described below:

1. Remove the receiver (T885 or T855) module from the Paragon3 unit rack frame
2. Remove the receiver top cover (nearest the handle).
3. Connect the Paragon3 unit's Extender Rail Kit for Series II to the empty chassis receiver slot.
4. Prepare the Multimeter to DC Volts.
5. Apply power to the Paragon3 base station.

6.2.2.2 Synthesizer Alignment

Single channel: Connect the Multimeter to either side of L504 (T885) or the long lead of L1 (T855) in the VCO (this measures the synthesizer loop voltage).

1. T885 (800 MHz) Tune VCO trimmer CV500 for a synthesizer loop voltage of 10VDC.
2. T855 (UHF) Tune VCO trimmer C6 for a synthesizer loop voltage of 10V DC.

Multiple channels (adjusting as shown for single channel above):

1. T885 (800 MHz) Adjust the VCO loop to 10V using the middle frequency channel.
2. T855 (UHF) Adjust the VCO loop to 10V using the middle frequency channel.
3. All channels should lie within the upper and lower limits of respectively
All channels should lie within the upper and lower limits of 16V and 3V respectively for the T885 and T855 or within 13V.

6.2.2.3 Front-End Alignment

1. IFR COM120B settings:
 - a) Connect a 3 feet long double shielded cable (N-M to BNC-M) between the IFR T/R output and the receiver antenna connector.
 - b) Select the generator mode (GEN button) and set to the main receiver channel frequency
 - c) Select and turn-on GEN2
 - d) Set the FM Deviation to ± 3 kHz (25 kHz channel) using 1KHz sine
 - e) Select SINAD meter
 - f) Use a X1 scope probe connected to SINAD input and monitor the Discriminator O/P on the back-plane at J1 pin 6 (RX-audio1). Alternately, it is also possible to monitor at the receiver I/O Pad P207 (T885) or at the receiver TP314 (T855).
2. Adjust the helical resonators for best SINAD: #H400, #H401 and #H900 (T885) or #FL410 and #FL420 (T855).
3. Continually decrease the RF level to reach 12dB SINAD, then re-do step 2) & 3) again. The absolute minimum requirement level to reach is -108dBm (typical level is -109 to -110 dBm)
4. Perform the SINAD linearity tests described in paragraph 6.2.2.4. If it fails to pass the requirement, contact your Dataradio technical support.

***WARNING: Do NOT attempt to re-tune the IF stages
(I.e. L300; L301; C311; C314; C318; C329; C331 and C336 for T885 or L310 to L390 for T855).***

These adjustments do not need to be re-adjusted after frequency re-programming. Touching these coils will have a direct impact on the modem DSP ISI coefficient settings and may significantly reduce the radio performances over data.

6.2.2.4 SINAD and Linearity Check

1. Apply the following settings to the IFR COM-120:
 - a) Generator mode, Output T/R, TX frequency to match the main radio RX frequency
 - b) Filter set to wide band (no audio filter)
 - c) Select Gen2 (Modulating tone fixed to 1kHz). All other Gen must be off.
 - d) Set deviation to ± 3.0 kHz (25 kHz channel)
 - e) Use a X1 scope probe connected to the IFR SINAD input and monitor the Discriminator O/P on the radio backplane at J1 pin 6 (RX-audio1). Alternately, it is also possible to monitor at the receiver I/O Pad P207 (T885) or at the receiver TP314 (T855).
2. Lower the RF level to get a 12dB SINAD reading. Level should be better than -108dBm (including cable loss).
3. Offset the IFR TX frequency 2 kHz (25 kHz channel) above the main radio RX frequency, record the SINAD reading. It should remain within 1.5 dB from the on frequency SINAD reading.
4. Offset the IFR TX frequency 2 kHz (25 kHz channel) below the main radio RX frequency, record the SINAD reading. It should remain within 1.5 dB from the on-frequency SINAD reading.

Note: If one of the above requirements is not met, try to re-tune the front-end. If still failed, contact your Dataradio technical support.

6.2.2.5 RSSI Adjustment

- Caution: misadjusting RSSI may reduce the base station's PD™ (Parallel Decode) performance.
- BSC must be connected to the radio backplane via the extender card during this process.

T885-xx-0200 (800 MHz) and T855-xx-0250 (UHF) receivers:

- Apply an on-channel signal from the RF generator at a level of -110 dBm modulated by a 1 kHz tone at a deviation of ± 3 kHz (25 kHz channel).
- Adjust RV 345 (RSSI level) for T885, RV320 (RSSI level) for T855 to give 2.0V RSSI output at SK330 pin 2 (T855) or on backplane J1 (RX1) or J5 (RX2) pin 5 when measured with a voltmeter (See Figure 3 for test point location).

The following RSSI graphic is given as general information only.

Refer to factory technical support **only** if RX data performance degradation is noticed combined with something that does not look like those RSSI curves.




Figure 88 - T855 and T885, Typical RSSI Curve: volt to dBm

6.2.3 Exciter Module (T881-xx-0200 or T857-xx-0250)

Note 1: Refer to Figure 91 (T881) and Figure 93 (T857) for locating tuning controls and components.

Note 2: When the synthesizer is unlocked, the front panel green LED called "Supply" will flash indicating that it needs re-tuning.

Warning:

The LED will also flash when the unit is in setup mode while connected to the PGM800win program.

6.2.3.1 Initial Setup

1. Shut down power to the base station.
2. Prepare the Multimeter to DC Volts.
3. Remove the exciter (T881 or T857) module from the base station rack frame.
4. Remove the exciter top cover (nearest the handle).
5. Connect a 3 feet long double-shielded cable (N-M to BNC-M) between the IFR T/R output and the exciter antenna connector.
6. Connect the Paragon3 base station Extender Rail Kit to the empty chassis exciter slot.
7. Apply power to the base station.

6.2.3.2 Synthesizer Alignment

Single channel: Connect the Multimeter to either side of L309 (T881) or the long lead of L1 in the VCO (T857) (this measures the synthesizer loop voltage).

1. T881 (800 MHz) Tune VCO trimmer CV300 for a synthesizer loop voltage of 10V DC.
2. T857 (UHF) Tune VCO trimmer C6 for a synthesizer loop voltage of 10V DC.

Multiple channels (adjusting as shown for single channel above):

1. T881 (800 MHz) Adjust the VCO loop to 10V using the middle frequency channel.
2. T857 (UHF) Adjust the VCO loop to 10V using the middle frequency channel.

All channels should lie within the upper and lower limits of 16V and 3V respectively for the T881 and T857 or within 13V.

Note:

Normally, the fast TX key option is installed and the synthesizer is always energized. In the case where that option was not fitted, key the transmitter by pressing the front panel Carrier button to make the above adjustment possible.

6.2.3.3 TX Frequency Error Adjustment

1. Apply the following settings to the IFR:
 - Receiver mode
 - IFR RX frequency to match the main radio TX frequency
 - IF Filter set to 30 kHz
 - Zoom the RF Error window: select 10 kHz range
2. Key the transmitter by pressing the front panel TX-Key button and measure the carrier output frequency. It should be within ± 300 Hz. If it is not, adjust the TCXO (IC700) to trim to meet the requirement, preferably within 100 Hz.

6.2.3.4 Low-Frequency Balance Adjustment

Note:

- *PGM800Win version 3.00 or later must be used. Electronic potentiometer (256 step) is used to allow channel adjustment of two-point modulation (Low freq. balance).*
1. Apply the following settings to the IFR:
 - Receiver mode and Oscilloscope display (Source Demod out connector, DC coupled).
 - IFR RX frequency to match the radio transmit frequency
 - IF Filter set to 30 kHz
 - Zoom the Deviation window: select 10 kHz Range and DC coupling.
 2. Select the active or, the lowest (in the case of multi-channel base) frequency channel (via dip switch, refer to Figure 87)
 3. From the web interface “Radio” page (“RF Test Tone”), select 100 Hz square wave – Press Execute. Transmit a square wave and follow the procedure outlined in Table 7 at step 7.
 4. Via PGM800Win, press EPOTs button. Adjust IC220 “reference modulation” to obtain the best square wave, no damping, no overshoot. (You can use either the mouse or up and down arrow keys). Record the deviation read.
 5. If transmission has not ended by itself, select “Cancel current test” to stop it. For single-channel unit, proceed to step 8.
 6. For multi-channel unit, select the highest frequency channel. From the web interface “Radio” page (“RF Test Tone”), select 100 Hz square wave – Press Execute. Transmit a square wave and follow the procedure outlined in Table 7 at step 7. Record deviation again.
 7. The difference in deviation between the two channels should be less than ± 300 Hz. If not, re-adjust IC220 to “average” the square wave shape on both channels until the spec is met.
 8. To confirm the adjustment, select the active, or the lowest frequency channel. Compare the deviation produced between 1000 Hz sine wave test tone and Random data test pattern
The difference between the test tone and the test pattern should be: < 2.5 kHz
For multi-channel unit, repeat this step for each frequency channel.
 9. Select the active channel. From the web interface “Radio” page (“RF Test Tone”), select modulated – Press Execute and follow the procedure outlined in Table 7 step 6. *Make sure that deviation level read on the IFR corresponds to model and bit rate in use as shown in the second column from the left.* Re-adjust deviation as necessary referring to Checklist B (Table 7) at step 6.

6.2.3.5 Exciter Power Output

1. Apply the following settings to the IFR:
 - Receiver mode, Output T/R
 - IFR RX frequency to match the main radio TX frequency
 - IF Filter set to 30 kHz
 - Select auto range in the *Power reading* window
 - Connect the coaxial cable from the IFR T/R to the Exciter output connector
2. Key the Exciter by pressing the module PTT button. The output power at the coaxial cable end connecting to the power amplifier should be:
 - UHF (T857) = $1\text{W} \pm 300\text{mW}$ (no adjustment provided)
 - 800 MHz (T881) = $4\text{W} \pm 300\text{mW}$ (RV502, Figure 91)

6.2.4 Power Amplifier Module (T889 (800-870 MHz only) or T859 UHF)

- Re-install the exciter module into the Paragon3 rack frame.
- Connect the Exciter module to the Power Amplifier.
- Connect the Power Amplifier output to the IFR T/R connector or to a stand-alone BIRD style power meter, terminated with a 150W dummy load.
- Forward and reverse “power alarm set” (controls) are identified on the PA cover.

6.2.4.1 Power Amplifier Power Output

- Key the transmitter on the exciter and adjust the PA output for required output (max 100W for UHF and max 70W for 800) using the front panel power control

If power cannot be reached, refer to section 6.2.4.4 for T859 UHF model, or factory technical support for T889 models. Cable loss should be included in the reading.

6.2.4.2 Forward Power Alarm Level (Optional setting)

1. Power up the PA and adjust front panel power control so that the output power is at the alarm level required, usually 20% lower than nominal value (e.g. 40W if the PA normally operates at 50W).
2. Adjust the forward power alarm set (T889: RV101 and T859: RV48) so that the forward power alarm LED lights.
3. Adjust front panel power control for the normal operating power level

6.2.4.3 Reverse Power Alarm Level (Optional setting)

1. Power up the PA and adjust the front panel power control for the normal operating power level.
2. Connect an unterminated 3dB 150 W pad to the PA output (e.g. 3:1 VSWR) and adjust the reverse power alarm set (T889: RV105 and T859: RV52) so that the reverse power alarm LED lights.

6.2.4.4 Tait T859 (UHF) Standard Tuning Procedure

1. For sets with serial numbers following 217262, set RV69 (driver power level) fully clockwise.
2. For all units, preset the tuning controls as shown below:










	450MHz	485MHz	520MHz
CV32, CV51, CV57			
CV34, CV35			
CV8, CV1			

Figure 89 - T859 Tuning settings

3. Set RV63 (front panel power control) fully clockwise.
4. Key on the exciter (press PTT button).
5. Adjust CV1 for maximum output.
6. Adjust CV8 for maximum output.
7. Adjust CV32 for maximum output.
8. Adjust CV51 and CV57 for maximum output.
9. Adjust CV34 and CV35 for maximum output.
10. Recheck all settings. The power output should exceed 110W.
11. For sets with serial numbers following 217262, adjust RV69 (driver power level) until the output power drops to 110W.
12. For all units, adjust RV63 (front panel power control) to reduce the power output to the required level (normally 100W).

6.2.4.5 Tait T859 Tuning for Best Efficiency

1. Insert a Shunt current device (HP 34330A Shunt 30A) between the power supply red wire and its 13.8Vdc output, then connect the shunt to the multimeter (VDC scale)
2. While transmitting, monitor the current. It should remain under 22A.
3. Retune CV32, CV51 and CV57 towards maximum capacitance to obtain minimum supply current, but do not exceed a maximum drop of 0.5A per control.
4. Check that the supply current is <22A for 100W output power.

Note: These control settings are normally very close to minimum supply current. If the current is reduced too far, maximum power output will drop and 2f rejection may degrade.




Figure 91 - T881-0200 Exciter Tuning Controls location




Figure 92 - T855 Receiver Tuning Controls location




Figure 93 - T857 Exciter Tuning Controls location




Figure 94 - T835 Receiver Tuning Controls Location




Figure 95 - T837 Exciter Tuning Controls location

7. Specifications

GENERAL	UHF	800MHz	800MHz (NPSPAC)
Frequency Range (MHz)	FCC = 403 – 512 Rx/Tx IC = 406 – 470 Rx/Tx	FCC = 854 – 869 Tx 809 – 824 Rx IC = 851 – 866 Tx 806 – 821 Rx	FCC = 851 – 854 Tx 806 – 809 Rx
	FCC Part 90 / IC RSS-119		
Channel Spacing	12.5 kHz / 25 kHz	25 kHz	25 kHz (NPSPAC)
Mode of Operation	Full Duplex, 100% duty cycle		
Cabinet Size	22.06" W x 75.82" H (without leveling feet) x 27.06" D		
RF/Modem Assembly Size	(Rackmount) 19.0" W x 8.75" H x 12.75" D + 2.0" connector allowance		
Power Supply Assembly Size	(Rackmount): 19.0" W x 3.5"H x 11" D		
Frequency Stability	1.0 ppm (-4°F to +140°F / -20°C to +60°C)		
Supply Voltage	120 VAC / 6A max, 60 Hz to 13.8 VDC or 13.8 VDC nominal, negative ground (12.6 to 14.6 VDC with Tait PA)		
Circuit protection (radio backplane)	Main fuse (F1): Blade fuse (Maxi-Fuse) 10A : Power amp. fuse (F2 & F3): Blade fuses (Maxi-Fuse) 2 x 15A (30A total) Crowbar diodes for reverse polarity protection		
RX Current Consumption @ 13.8 VDC	1.5A max. (Two receivers with speaker monitoring)		
TX Current Consumption @ 13.8 VDC	24A (22A DC typical @ 450 MHz for 100W)	28A (23A DC typical @ 850 MHz for 70W)	
Operating Temperature Range	-22°F to +140°F / -30°C to +60°C (Deleted power supply, catalog number with 0 in second to last digit) +14°F to +140°F / -10°C to +60°C (with standard Dual Power Supply assy., catalog number with 2 in second to last digit)		

Modem / Network

User Interface	<ul style="list-style-type: none"> Dual Ethernet RJ45 Auto MDIX 10-100/T with LED status indicators Dual RS-232 DB-9F Serial Ports configured as Terminal Servers USB Port (future use) 			
Addressability	Native TCP/IP and built-in router			
Data Encryption	AES 128-bit			
Protocols	<ul style="list-style-type: none"> Dataradio Proprietary E-DBA with OOB AAVL support Ethernet IEEE 802.3, (ICMP, IGMP, TCP, UDP) IP Fragmentation, Address Resolution Protocol (ARP) IP directed broadcast, IP limited broadcast, IP multicast relay DHCP client and server Network Address Translation (NAT), Dynamic Routing (RIPv2) 			
Data rates	12.5 kHz ch.:	25 kHz ch.:	25 kHz ch.:	NPSPAC ch.:
	32 kbps	64 kbps	64 kbps	32 kbps
	24 kbps	48 kbps	48 kbps	24 kbps
	16 kbps	43.2kbps	43.2kbps	16 kbps
		32 Kbps	32 Kbps	

Radio	UHF 25kHz Channel	UHF 12.5 kHz Channel	800MHz 25 kHz Channel	800MHz NPSPAC Channel
Receiver Sensitivity (For 1% Packet Error Rate (PER) with Parallel Decode at carrier frequency)	-97 dBm @ 64 kbps -103 dBm @ 48 kbps -106 dBm @ 43.2 kbps -109 dBm @ 32 kbps	-100 dBm @ 32kbps -106 dBm @ 24kbps -109 dBm @ 16kbps	-94 dBm @ 64 kbps -100 dBm @ 48 kbps -104 dBm @ 43.2 kbps -106 dBm @ 32 kbps	-103 dBm @ 32kbps -109 dBm @ 24kbps -115 dBm @ 16kbps
Selectivity (@ 25kHz)	87 dB min, 90 dB (Typical)	83 dB min, 85 dB (Typical)	85 dB min, 88 dB (Typical)	79 dB min, 80 dB (Typical)
Spurious Response Rejection	100 dB (Typical)			
Intermodulation Rejection - EIA (25 kHz)	85 dB (Typical)	80 dB (Typical)	80 dB (Typical)	75 dB (Typical)
Receiver Frequency range	403 – 512 MHz		806 – 824 MHz	806 – 809 MHz
Transmitter Frequency range	403 – 512 MHz		851 – 869 MHz	851 – 854 MHz
Power Output (user adjustable)	20 –100 W		20 – 70 W	
Spurious Emissions: - transmit - standby	-36 dBm to 1 GHz, -30 dBm to 4 GHz (to 3.2GHz for 800/900 model) -57 dBm to 1 GHz, -47 dBm to 4 GHz ((to 3.2GHz for 800/900 model))			
VSWR Stability	5:1 mismatch			

FCC / IC CERTIFICATIONS		FCC (Part 90)	IC (DOC, RSS119)
UHF	400 – 440 MHz	EOTBDD4T85-1	773A-BDD4T85
	440 – 480 MHz	EOTBDD4T85-2	
	480 – 520 MHz	EOTBDD4T85-3	N/A
800 MHz	850 – 870 MHz	EOTBDD4T889 (70 Watts) EOTBDD4T881S2 (5 Watts Exciter)	773A-BDD4T89 773A-BDD4T88 (5 Watts Exciter)
800 MHz NPSPAC	850 – 870 MHz	EOTBDD4T889 (70 Watts) EOTBDD4T881S2 (5 Watts Exciter)	

EMISSION DESIGNATORS

Bit rate	Baud rate	Modulation	UHF	800MHz
64000	16000	SRRC16FSK	16K5F1D (C) ¹	13K6F1D (G) ²
48000	16000	SRRC8FSK	16K5F1D (C)	13K6F1D (G)
43000	14400	SRRC8FSK	16K2F1D (C)	13K4F1D (G)
32000	18000	SRRC16FSK	8K50F1D (D) ³	10K0F1D (H) ⁴
24000	8000	SRRC8FSK	8K50F1D (D)	10K0F1D (H)
16000	8000	SRRC4FSK	8K50F1D (D)	10K0F1D (H)

¹ FCC mask C (UHF, 25kHz ch.)

² FCC mask G (800MHz, 25kHz ch.)

³ FCC mask D (UHF, 12.5kHz ch.)

⁴ FCC mask H (800MHz, NPSPAC ch.)

Appendix 1 - "GPS Data Collection" Instructions

The extract in this appendix is taken from Technical Instruction Sheet 043 (TIS043), dated May 03, 2006.

Overview

The instructions in TIS043 are intended for application programmers and provide details on how to collect GPS data in VIS networks using GPS-equipped GeminiG3 radio modems and Paragon3 base stations.

Data Flow

GPS "strings" are collected from the embedded GPS receiver in the GeminiG3 mobile radio modems. The strings are converted into DCF 2.0 ("Dataradio Compressed Format, version 2.0") reports and provided to both local delivery and remote delivery services. The remote delivery service of the GeminiG3 sends reports Out of Band (OOB) in any unused portion of control & data packets, where they are passed to the Paragon3 local delivery service.

For diagnostic purposes, GPS data can be displayed on both the GeminiG3 and Paragon3 unit web pages:

- Using a browser, basic information can be read on the GeminiG3 unit "GPS Status" web page.
- Using a browser, data from the last GPS report received from each mobile can be read on the Paragon3 unit "Remote Table" web page.

GPS data is also available to external applications via TCP or UDP.

Application Programmers

For further information, please contact Dataradio system engineering.

Appendix 2 - E-DBA Throughput/Latency Measurements Methods

The contents of this appendix is also available in Technical Instruction Sheet 044 (TIS044), dated March 01, 2006.

Overview

The instructions in TIS044, intended for end-users, discuss the effectiveness of TCP/IP troubleshooting tools in E-DBA networks. It shows how to assess network performance in the E-DBA environment. It is reproduced here to complement the information given in section 5.4

Performance Metrics

The following metrics are typically used to measure communication network performance:

- ◆ Latency Also called “Response Time”. In this context, latency measures the amount of time it takes for a response to return from a request. It takes into account the delays accumulated at every step of the round trip.
Usually expressed in seconds or milliseconds.
- ◆ Throughput The amount of information that can be transferred over a connection in a given period of time.
Usually expressed in bits per second (bps), bytes per second (Bps) or packets per seconds (pps)

E-DBA Primer

E-DBA is a *scheduled air-link protocol* whose algorithms were designed to favor throughput over latency. To achieve that goal, the air-link uses adaptive timeslots called *cycles* to schedule traffic. These cycles dynamically vary in length (typically, between 200 to 1500 milliseconds) based on various factors, including network load.

Each packet of data transiting through an E-DBA network must therefore be scheduled for transmission, which introduces a *scheduling latency* of one or more cycles.

PING as a Performance Measuring Tool

Ping is a utility used to determine whether a particular IP address is reachable by sending out a packet and waiting for a response. It is therefore a good tool to measure network latency.

Because of E-DBA’s cycle mechanism, a ping packet could take up to 3 cycles to make the round trip, producing an unexpectedly large ping time even when the radio channel is lightly loaded. For this reason, Dataradio recommends that ping should only be used to verify if a device is reachable, not as a measure of network performance.

On Ethernet-only networks, ping is normally set to timeout its request packets after 1 or 2 seconds. When using ping over an E-DBA network, Dataradio recommends setting the ping timeout to 5000 milliseconds or more.

PING Example

```
C:\>ping -w 5000 172.23.10.2

Pinging 172.23.10.2 with 32 bytes of data:

Reply from 172.23.10.2: bytes=32 time=641ms TTL=59
Reply from 172.23.10.2: bytes=32 time=703ms TTL=59
Reply from 172.23.10.2: bytes=32 time=593ms TTL=59
Reply from 172.23.10.2: bytes=32 time=641ms TTL=59

Ping statistics for 172.23.10.2:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 593ms, Maximum = 703ms, Average = 644ms
```

TRACEROUTE (TRACERT) as a Performance Measuring Tool

Traceroute, *named tracert in Windows™ environments*, is a utility that describes the path in real-time from the client machine to the remote host being contacted. It reports the IP addresses of all the routers in between. It also reports the latency delays encountered at each hop. As with ping, E-DBA's cycle mechanism may produce an unexpectedly large delay when traversing an E-DBA airlink.

A large timeout value is also recommended when using Traceroute.

TRACEROUTE Example

```
C:\>tracert -w 5000 172.23.10.2

Tracing route to 172.23.10.2 over a maximum of 30 hops

  1    <10 ms    <10 ms    <10 ms    192.168.36.37    (host→base)
  2    641 ms    734 ms    750 ms    172.23.10.2      (host→base→mobile)

Trace complete.
```

FTP as a Performance Measuring Tool

FTP is a protocol used to transfer files over a TCP/IP network. Applications that implement that protocol are good candidates for measuring the throughput of a link. Note that the FTP & TCP/IP software components in the server and client computers may have an adverse effect on performance – factors such as FTP buffer size, TCP window size and the TCP congestion-control algorithm may interact to produce throughput lower than that of the theoretical maximum. As well, be careful about inferring total system performance from the result of a single FTP transfer.

Conclusion

Although some standard tools such as the ones outlined above can be used to get a rough idea of an E-DBA system's performance, the best metric will always be to test the system in conditions that reproduce as closely as possible its real-life usage. For example, by using applications similar to wireless CAD systems and the appropriate traffic profile.

Appendix 3 - Time Synchronization, and WEB Browser Cache - Instructions

The contents of this appendix is also available in Technical Instruction Sheet 051 (TIS051), dated November 10, 2006.

Overview

The instructions in TIS051, intended for maintenance technicians and for end-users, address a built-in web server synchronization and browser cache issue where web pages of a unit may contain information that does not seem to match the expected content, especially after a firmware upgrade.

The following paragraphs detail the cause of the problem and steps to prevent the problem.

Likely Cause

Most web browsers store the pages they display in a browser cache, so that the next time the same page is displayed, the browser does not have to download it all over again from the server. The browser instead displays the version of the page that was previously stored in the cache.

This process relies on a combination of factors to establish whether a page can be retrieved from the cache or must be freshly downloaded from the server. Typically, they are:

- ◆ The IP address of the server
- ◆ The time and date the page was last updated on the server.

Unless your unit was configured to pick up and maintain time-of-day (section 4.7.3.7), its time and date restarts from the same point (typically, 1970-01-01 00:00:00*) after each reset or power-up. In this condition, the timestamp applied to web pages during a firmware upgrade might pre-date the timestamp of the pages already in the browser's cache. When next accessing the pages in question, the browser will pickup the cached version, as it appears to be newer than that of the freshly upgraded unit.

** Encoded system time using the number of one-second ticks elapsed since the start of the "epoch" set at 1970-01-01 00:00:00 Z.*

Problem Prevention

In order to avoid picking up stale data, it is strongly recommended that you empty the browser's cache before starting to browse the web content of a unit, following a software update, and when going from one unit to another.

Enabling time-of-day synchronization (*on units that support it*) will also help prevent this problem.

Cache Clearing

If using Internet Explorer v6.0, select "Tools" in the menu bar, select "Internet Options", select the "General" tab and click on the "Delete Files" button in the "Temporary Internet files" pane; click on the "OK" button to confirm the deletion and on the OK button to exit.

If using Mozilla Firefox v1.5.0.4, select "Tools" in the menu bar and select the "Clear Private Data" option. Alternately, you can use the keystroke combination of "Ctrl+Shift+Delete".

Adjust the above methods according to your browser or to its version number.

Appendix 4 - Ethernet Configuration - Recommendation

The contents of this appendix is extracted from Technical Instruction Sheet 052 (TIS052), dated December 06, 2006.

Overview

The recommendation in TIS052, intended for maintenance technicians and for end-users, addresses an issue where communication fails when trying to connect, or attempting to FTP files to upgrade a unit.

Ethernet Network Port Setting

For all Paragon3, always use half duplex. Dataradio recommends using 100BaseT unless network connectivity problems arise; in which case, lower the Ethernet port to 10BaseT.

FTP Connection Failure Indication

FTP transfer stops on one of the transfer steps and displays a message similar to:

```
>Netout: Connection reset by peer
Connection closed by remote host.
ftp>
```

FTP Recommendation

Certain Ethernet cards have (*as default*) the option to calculate the Rx/Tx checksum through the hardware on the Ethernet card instead of the OS. These cards can have bugs and sometimes get the wrong CRC result, resulting in dropped packets and connectivity failure. If having connectivity problems configuring an Ethernet card, change the following parameters to “Disable”:

- ◆ Rx Checksum Offload
- ◆ Tx Checksum Offload

Even though this Ethernet card issue occurred when running Windows XP Professional SP2, as well as Windows 2000, we believe it could manifest itself under other (or older) operating systems, with a variety of network cards, and on other Dataradio radio modem products.



**DATARADIO is a registered trademark,
GeminiG3, Paragon3 and PARALLEL DECODE are trademarks of Dataradio Inc**